

Version
July 2013

Add-on Module

RF-STEEL

**Stress Analysis for
Surfaces and Members**

Program Description

All rights, including those of translations, are reserved.

No portion of this book may be reproduced – mechanically, electronically, or by any other means, including photocopying – without written permission of DLUBAL SOFTWARE GMBH.

© **Dlubal Software GmbH**

Am Zellweg 2 D-93464 Tiefenbach

Tel.: +49 9673 9203-0

Fax: +49 9673 9203-51

E-Mail: info@dlubal.com

Web: www.dlubal.com

Content

	Content	Page		Content	Page
1.	Introduction	4	3.3	Results	60
1.1	RF-STEEL Add-on Modules	4	3.3.1	Stresses by Cross-Section	61
1.2	RF-STEEL Team	5	3.3.2	Stresses by Set of Members	63
1.3	Using the Manual	6	3.3.3	Stresses by Member	64
1.4	Start RF-STEEL Modules	6	3.3.4	Stresses by x-Location	65
2.	RF-STEEL Surfaces	8	3.3.5	Stresses at Every Stress Point	66
2.1	Input Data	8	3.3.6	Governing Internal Forces by Member	67
2.1.1	General Data	8	3.3.7	Governing Internal Forces by Set of Members	68
2.1.1.1	Ultimate Limit State	10	3.3.8	Parts List by Member	69
2.1.1.2	Serviceability	11	3.3.9	Parts List by Set of Members	70
2.1.2	Materials	12	4.	Results Evaluation	71
2.1.3	Surfaces	16	4.1	RF-STEEL Surfaces	73
2.1.4	Serviceability Data	18	4.1.1	Selection of Stresses	73
2.2	Calculation	19	4.1.2	Results in RFEM Model	74
2.2.1	Detail Settings	19	4.2	RF-STEEL Members	77
2.2.1.1	Stresses	19	4.2.1	Selection of Stresses	77
2.2.1.2	Serviceability	24	4.2.2	Results on Cross-Section	78
2.2.1.3	Options	25	4.2.3	Results in RFEM Model	80
2.2.2	Start Calculation	27	4.2.4	Result Diagrams	83
2.3	Results	29	4.3	Filter for Results	84
2.3.1	Stresses by Load Case	30	5.	Printout	86
2.3.2	Stresses by Material	33	5.1	Printout report	86
2.3.3	Stresses by Surface	33	5.2	Printing RF-STEEL Graphics	86
2.3.4	Stresses by Line	34	5.2.1	Results in the RFEM Model	86
2.3.5	Stresses in All Points	35	5.2.2	Results on Cross-section	88
2.3.6	Stress Ranges	36	6.	General Functions	90
2.3.7	Displacements	37	6.1	Design Cases	90
2.3.8	Parts List	38	6.2	Optimization	92
3.	RF-STEEL Members	40	6.2.1	RF-STEEL Surfaces	92
3.1	Input Data	40	6.2.2	RF-STEEL Members	93
3.1.1	General Data	40	6.3	Units and Decimal Places	96
3.1.2	Materials	42	6.4	Data Transfer	97
3.1.3	Cross-Sections	47	6.4.1	Material Export to RFEM	97
3.2	Calculation	51	6.4.2	Export of Results	97
3.2.1	Detail Settings	51	A	Literature	99
3.2.2	Stresses and Ratio	54	B	Index	100
3.2.3	Start Calculation	59			

1. Introduction

1.1 RF-STEEL Add-on Modules

Both RF-STEEL add-on modules are integrated in the graphical user interface of the RFEM program. **RF-STEEL Surfaces** is used for the stress and serviceability limit state design of surface and shell elements. The stresses of member elements are designed by **RF-STEEL Members**. Both modules are described in this manual.

RF-STEEL performs general stress designs by calculating normal, shear, and equivalent stresses of surfaces, members, and sets of members and by comparing them with the limit stresses. The add-on modules provide a comprehensive library for cross-sections and materials with standard-specific limit stresses that can be adjusted and expanded. All member cross-sections are provided with design relevant stress points. The results of these points can also be used for graphical evaluations.

The design relevant input data of the model as well as the internal forces are imported automatically when you open the modules. After the design is carried out, you can evaluate the design results in the RFEM work window graphically and include them in the global printout report.

When you design members and sets of members, the internal forces that are found to be governing are displayed, too. In addition, RF-STEEL allows you to optimize the surfaces and cross-sections automatically and to export the changes to RFEM.

Using the so-called design cases, you can analyze the different types of stress designs. A parts list with quantity surveying completes the design.

The following useful features facilitate the work with RF-STEEL:

- Determination of equivalent stresses according to different approaches: VON MISES, TRESCA, RANKINE, or BACH
- Serviceability limit state design by checking surface displacements
- Output of stress ranges for fatigue designs
- Display of maximum stress ratios in surface and cross-section tables, helping you to decide how to carry out the optimization
- Connection between RF-STEEL tables and RFEM work window, thus selecting, for example, the current member of the table in the background graphic
- View mode to change the view in the RFEM work window
- Colored relation scales in results windows
- Info icon for successful or failed stress design
- Representation of RF-STEEL stresses and stress ratios in the form of result diagrams
- Filter function for surfaces, lines, and nodes in tables as well as stresses and stress ratios in the RFEM graphic
- Data export to MS Excel and OpenOffice.org Calc or as a CSV file

All this makes RF-STEEL the appropriate program for general stress analyses. Note, however, that stability analyses, as required for example in EN 1993-1-1 or DIN 18000 part 2, cannot be performed. For such analyses, the add-on modules RF-STEEL EC3 or RF-KAPPA and RF-LTB are recommended.

We hope you will enjoy working with the RF-STEEL add-on modules.

Your DLUBAL Team

1.2 RF-STEEL Team

The following people were involved in the development of RF-STEEL Surfaces and RF-STEEL Members:

Program coordination

Dipl.-Ing. Georg Dlubal

Dipl.-Ing. (FH) Younes El Frem

Programming

Ing. Ing. Zdeněk Kosáček

Mgr. Petr Oulehle

Dipl.-Ing. Georg Dlubal

Zbyněk Zámečník

Ing. Martin Budáč

Cross-section and material database

Ing. Ph.D. Jan Rybín

Ing. Jiří Kubíček

Mgr. Petr Oulehle

Program design, dialog figures, and icons

Dipl.-Ing. Georg Dlubal

Ing. Jan Milář

MgA. Robert Kolouch

Program supervision

Ing. Martin Vasek

M.Eng. Dipl.-Ing. (BA) Andreas Niemeier

Localization, manual

Ing. Fabio Borriello

Ing. Roberto Lombino

Ing. Dmitry Bystrov

Eng.º Nilton Lopes

Eng.º Rafael Duarte

Mgr. Ing. Hana Macková

Ing. Jana Duníková

Ing. Téc. Ind. José Martínez

Ing. Lara Freyer

MA SKT Anton Mitleider

Alessandra Grosso

Dipl.-Ü. Gundel Pietzcker

Bc. Chelsea Jennings

Mgr. Petra Pokorná

Jan Jeřábek

Ing. Zoja Rendlová

Ing. Ladislav Kábrt

Dipl.-Ing. Jing Sun

Ing. Aleksandra Kociołek

Ing. Marcela Svitáková

Mgr. Michaela Kryšková

Dipl.-Ing. (FH) Robert Vogl

Dipl.-Ing. Tingting Ling

Ing. Marcin Wardyn

Technical support

M.Eng. Cosme Asseya

Dipl.-Ing. (FH) Bastian Kuhn

Dipl.-Ing. (BA) Markus Baumgärtel

Dipl.-Ing. (FH) Ulrich Lex

Dipl.-Ing. Moritz Bertram

Dipl.-Ing. (BA) Sandy Matula

M.Sc. Sonja von Bloh

Dipl.-Ing. (FH) Alexander Meierhofer

Dipl.-Ing. (FH) Steffen Clauß

M.Eng. Dipl.-Ing. (BA) Andreas Niemeier

Dipl.-Ing. Frank Faulstich

Dipl.-Ing. (FH) Gerhard Rehm

Dipl.-Ing. (FH) René Flori

M.Eng. Dipl.-Ing. (FH) Walter Rustler

Dipl.-Ing. (FH) Stefan Frenzel

M.Sc. Dipl.-Ing. (FH) Frank Sonntag

Dipl.-Ing. (FH) Walter Fröhlich

Dipl.-Ing. (FH) Christian Stautner

Dipl.-Ing. Wieland Götzler

Dipl.-Ing. (FH) Lukas Sühnel

Dipl.-Ing. (FH) Andreas Hörold

Dipl.-Ing. (FH) Robert Vogl

Dipl.-Ing. (FH) Paul Kieloch

1.3 Using the Manual

Topics like installation, graphical user interface, results evaluation, and printout are described in detail in the manual of the main program RFEM. The present manual focuses on typical features of the RF-STEEL add-on modules.



The descriptions in this manual follow the sequence of the module's input and results windows as well as their structure. The text of the manual shows the described **buttons** in square brackets, for example [View mode]. At the same time, they are pictured on the left. **Expressions** appearing in dialog boxes, windows, and menus are set in *italics* to clarify the explanations.

At the end of the manual, you find the index. However, if you don't find what you are looking for, please check our website www.dlubal.com where you can go through our comprehensive FAQ pages by selecting particular criteria.

1.4 Start RF-STEEL Modules

RFEM provides the following options to start the RF-STEEL add-on modules.

Menu

To start the program in the RFEM menu bar, click

Add-on Modules → Design - Steel → RF-STEEL Surfaces or RF-STEEL Members.




Figure 1.1: Menu: Add-on Modules → Design - Steel → RF-STEEL Surfaces or RF-STEEL Members

Navigator

As an alternative, you can start the add-on modules in the *Data* navigator by clicking

Add-on Modules → **RF-STEEL Surfaces** or **RF-STEEL Members**.




Figure 1.2: Data navigator: Add-on Modules → RF-STEEL Surfaces or RF-STEEL Members

Panel

In case results from RF-STEEL Surfaces or RF-STEEL Members are already available in the RFEM model, you can also open the design modules in the panel:

Set the relevant RF-STEEL design case in the load case list of the RFEM toolbar. To display the stresses and stress ratios graphically, click [Show Results].

When the results display is activated, the panel is available, too. Now you can use the buttons [RF-STEEL Surfaces] or [RF-STEEL Members] to open the module.





Figure 1.3: Panel button [RF-STEEL Surfaces]

2. RF-STEEL Surfaces

2.1 Input Data

When you have started the add-on module, a new window opens. In this window, a Navigator is displayed on the left, managing the tables that can be selected currently. The drop-down list above the navigator contains the design cases (see chapter 6.1, page 90).

The design relevant data is defined in three input windows. When you open RF-STEEL Surfaces for the first time, the following parameters are imported automatically:

- Surfaces and surface thicknesses
- Load cases, load combinations, result combinations, and RF-DYNAM cases
- Materials
- Internal forces (in background, if calculated)

To select a table, click the corresponding entry in the navigator. To set the previous or next input window, use the buttons shown on the left. You can also use the function keys to select the next [F2] or previous [F3] window.

Click [OK] to save the results, thus exiting RF-STEEL and returning to the main program. If you click [Cancel], you exit the add-on module but without saving the data.



2.1.1 General Data

In window 1.1 *General Data*, you select the surfaces and actions that you want to design. The tabs manage the load cases, load combinations, and result combinations for the ultimate limit state and the serviceability limit state design.

The design standard will be specified in window 1.2 because the standard is related to the material properties.




Figure 2.1: Window 1.1: *General Data*

Design of




Figure 2.2: Design of surfaces



You can analyze plane and curved *Surfaces*. If you want to design only selected surfaces, clear the *All* check box. Then you can access the input field to enter the numbers of the relevant surfaces. The list of the numbers preset in the field can be selected by double-clicking and overwritten by entering the data manually. Use the button [↵] if you want to select the objects graphically in the RFEM work window.

Comment




Figure 2.3: User-defined comment

In this input field, you can enter user-defined notes describing in detail, for example, the current RF-STEEL design case.

2.1.1.1 Ultimate Limit State




Figure 2.4: Window 1.1: General Data, tab Ultimate Limit State

Existing Load Cases

In this column, all load cases as well as load and result combinations created in RFEM are listed.




Furthermore, RF-STEEL Surfaces is able to design RF-DYNAM cases.

Use the button [▶] to transfer selected entries to the list *Selected for Design* on the right side. You can also just double-click the entries to transfer them to the right side. To transfer the complete list to the right, use the button [▶▶].

To transfer multiple entries of load cases, click the entries while pressing the [Ctrl] key, as common for Windows applications. Thus, you can transfer several load cases at the same time.

Load cases that are marked by an asterisk (*), like load case 6 and 7 in Figure 2.4, cannot be designed: This happens when the load cases are defined without any load data or the load cases contain only imperfections. Then when you transfer the load cases, a corresponding warning appears.

At the end of the list, several filter options are available. They will help you assign the entries sorted according to load cases, combinations, or action categories. The buttons are reserved for the following functions:



	Select all cases in the list.
	Invert selection of load cases.

Table 2.1: Buttons in the tab Ultimate Limit State

Selected for Design

The column on the right lists the load cases as well as the load and result combinations selected for design. Use the button [◀] or double-click the entries to remove selected items from the list. Use the [◀◀] button to transfer the entire list to the left.



The design of an enveloping max/min results combination is performed faster than the analysis of all load cases and load combinations that have been globally set. However, when analyzing a result combination, the influence of the contained loads is difficult to recognize.

2.1.1.2 Serviceability

This tab is independent of the entries in the tab *Ultimate Limit State*.




Figure 2.6: Window 1.1 General Data, tab Serviceability Limit State

Existing Load Cases

In these two sections, all load cases as well as load and result combinations created in RFEM are listed.

Usually, different actions and partial safety factors are relevant for the design of serviceability limit states (SLS) than for the design of ultimate limit states. The corresponding combinations can be created in RFEM.

Selected for Design

Load cases as well as load and result combinations can be added or removed, as described in chapter 2.1.1.1 *Ultimate Limit State*.

In accordance with EN 1990, the load cases as well as the load and result combinations can be assigned to the following design situations:

- Characteristic
- Frequent
- Quasi-permanent

This classification determines which limit values of the deflection are applied. They can be adjusted for the individual action combinations in the dialog box *Details*, tab *Serviceability* (see chapter 2.2.1.2, page 24).

To modify the design situation, use the list which can be accessed at the end of the input field by clicking [▼].




Figure 2.7: Assign a design situation

The reference lengths that are decisive for the serviceability limit state design are determined in window 1.4 *Serviceability Data* (see chapter 2.1.4, page 18).

2.1.2 Materials

The window is subdivided into two parts. In the upper part, the design relevant steel grades are listed. All materials of the category "steel" that are used for surfaces in RFEM are already preset. In the *Material Properties* section, the properties of the current material, that is, the table row currently selected in the upper section, are displayed.




Figure 2.8: Window 1.2 Materials

Materials that will not be used in the design appear in gray lettering. Materials that are not allowed are highlighted red. Modified materials are displayed in blue.

The material properties required for the determination of internal forces are described in chapter 4.3 of the RFEM manual (*Main Properties*). The material properties required for design are stored in the global material library. The values are preset (*Additional Properties*).

To adjust the units and decimal places of material properties and stresses, use the module's **Settings** → menu **Units and Decimal Places** (see chapter 6.3, page 96).

Material Description

The materials defined in RFEM are already preset, but it is always possible to modify them: To activate the field, click the material in column A. Then click [▼] or press function key [F7] to open the material list.




Figure 2.9: List of steel grades

Only "Steel" materials are available in the list. In principle, you can carry out the design with other materials if their stress design concept is based on the comparison of existing normal, shear, and equivalent stresses with allowable stresses (for example the design of cross-sections consisting of aluminum or stainless steel). Of course, you must take into account further standard specifications additionally.

When you have imported a material, the design relevant *Material Properties* are updated.

Limit stresses of a material that is not allowed (for example coniferous timber) can be defined by means of *Yield Strength* (column C) or by selecting the check box *Manually* (column D) and entering user-defined specifications. When you have defined the allowable stresses in the columns E to G, the red color will disappear.

The import of materials from the library is described later.

Safety Factor γ_M

This factor describes the safety factor contained in the design values of the material stiffnesses. Therefore, *M* is indicated. By means of the factor γ_M , the characteristic value of the yield strength f_{yk} is reduced in order to determine the limit normal stress $\sigma_{R,d}$ (see Equation 2.1) and the limit shear stress $\tau_{R,d}$ (Equation 2.2).

Yield Strength $f_{y,k}$

The yield strength describes the limit to which the material can be strained without plastic deformation. The characteristic values of several steel grades can be found, for example, in EN 1993-1-1, section 3 or DIN 18800 part 1, section 4.

When modifying the yield strength, the limit stresses in the columns E, F and G are adjusted automatically.

For some materials, there is a relation between the characteristic yield strength $f_{y,k}$ and the thickness *t* of the relevant structural component. In the section *Material Properties*, the *Thickness Range* of the material selected above is shown with the corresponding yield strength.

The zones of the yield strength are specified in the standards, for example in DIN 18800 part 1, table 1. Click [Edit] to control and, if required, adjust the thicknesses of structural components including yield strength (see Figure 3.8, page 46).

Limit Stresses

The limit stresses of materials that are stored in the material library are preset.

If you want to adjust the limit stresses, you can use the check box *Manually* or the button [Edit Material] (see Figure 3.8, page 46).

Manually

If the check box is selected, you can define the limit stresses in the columns E to G manually.

Modified material properties are marked by an asterisk in the column *Material Description*.

Limit σ_x

The limit normal stress represents the allowable stress for actions due to bending and axial force. According to for example DIN 18800 part 1, el. (746), it is determined by the characteristic value of the yield strength, reduced by the partial safety factor γ_M .

$$\sigma_{x,R,d} = \frac{f_{yk}}{\gamma_M}$$

Equation 2.1



Material No.	A Material Description
1	Steel S 235*

Limit τ

The limit shear stress indicates the allowable shear stress due to shear force and torsion. To determine the limit shear stress according to DIN 18800 part 1, el. (746), the partial safety factor γ_M is also included in the equation used to determine the limit shear stress.

$$\tau_{R,d} = \frac{f_{yk}}{\gamma_M \cdot \sqrt{3}}$$

Equation 2.2

Limit σ_{eqv}

The limit equivalent stress represents the allowable equivalent stress for the simultaneous effect of several stresses. According to DIN 18800 part 1, el. (746), it is determined by Equation 2.1.

Material Library

Numerous materials are already available in the library. To open the corresponding dialog box, click



Edit → Material Library

or use the button shown on the left.





Figure 2.10: Dialog box *Material Library*

In the *Filter* section, *Steel* is preset as material category. Select the steel grade that you want to use for the design in the list *Material to Select*. The corresponding properties can be checked in the dialog section below.



Click [OK] or use the [-] button to transfer the selected material to window 1.2 of the add-on module RF-STEEL Surfaces.

Chapter 4.3 in the RFEM manual describes in detail how materials can be filtered, added, or rearranged.

You can also select materials of categories like *Cast Iron* or *Stainless Steel*. Please check, however, whether these materials are allowed by the standard's design concept.

Edit Material



The yield strengths and limit stresses of the currently selected material can be adjusted by clicking the button shown on the left. The following dialog box appears:




Figure 2.11: Dialog Box *Edit Material*

In the section *Yield Strengths and Limit Stresses Subject to Component Thicknesses*, the limits of the *Component Thickness t* can be shifted by manually entering values in column B. The number of ranges is defined in the standards.

If the check box *User-defined, independent definition of limit stresses* is selected, you can define the limit stresses for each range individually. If this check box is not active, the limit stresses are determined by the yield strength $f_{y,k}$ (column C) and the Safety Factor γ_M according to Equation 3.1 and Equation 3.2.

2.1.3 Surfaces

This window manages the surfaces selected for design in window 1.1 *General Data*. In addition, optimization parameters can be specified.

1.3 Surfaces

Surface No.	A Material No.	B Thickness Type	C d [mm]	D Optimize	E Remark	F Area A [cm ²]	G Mass G [t]	H Comment
51	1	Constant	6.0	<input type="checkbox"/>		127626	0.60	
52	1	Constant	6.0	<input type="checkbox"/>		127626	0.60	
53	1	Constant	6.0	<input checked="" type="checkbox"/>	7)	11900	0.06	
54	1	Constant	30.0	<input type="checkbox"/>		1613	0.04	
55	1	Constant	30.0	<input type="checkbox"/>		1600	0.04	
56	1	Constant	30.0	<input type="checkbox"/>		11288	0.27	
57	1	Constant	30.0	<input type="checkbox"/>		1600	0.04	
58	1	Constant	30.0	<input type="checkbox"/>		1613	0.04	
59	1	Constant	30.0	<input type="checkbox"/>		11900	0.28	
60	1	Constant	30.0	<input type="checkbox"/>		11287	0.27	
61	1	Constant	30.0	<input type="checkbox"/>		11288	0.27	
62	1	Constant	30.0	<input type="checkbox"/>		11900	0.28	
63	1	Constant	30.0	<input type="checkbox"/>		11288	0.27	
64	1	Variable		<input type="checkbox"/>	2)	11900	0.16	
65	1	Variable		<input type="checkbox"/>	2)	875	0.01	
66	1	Constant	15.0	<input type="checkbox"/>		875	0.01	
67	1	Constant	15.0	<input type="checkbox"/>		875	0.01	
68	1	Constant	15.0	<input type="checkbox"/>		875	0.01	

1 - Steel S 275JR
EN 10025:1994-03

7) The thickness is not the same as that given in RFEM.

Figure 2.12: Window 1.3 Surfaces

Material No.

The numbers of the materials managed in window 1.2 *Materials* are shown for every surface.

Thickness

Type

The design is only possible for surfaces with isotropic properties with constant or linearly variable thickness. Surfaces with orthotropic properties cannot be designed.

d


This column shows the surface thicknesses defined in RFEM. You can modify the values for the design.



If you modify the surface thicknesses, the internal forces from RFEM resulting from the RFEM surface thicknesses will be used for the design. If you have a statically indeterminate system, you have to adjust the thicknesses modified in RF-STEEL Surfaces in RFEM as well. In this way, the distribution of internal forces will be considered for the design correctly.

Max. Stress Ratio

This column will be shown after the calculation. It is a decision support for the optimization. By means of the displayed design ratio and colored relation scales, you can see which surfaces are little utilized and thus oversized, or overloaded and thus undersized.



Optimize

For each surface, you can carry out an optimization process. For the RFEM internal forces, the program determines the surface thickness that comes as close as possible to a user-defined maximum ratio. The maximum ratio can be defined in the dialog box *Details*, tab *Options* (see Figure 2.17, page 25).

If you want to optimize a surface, select the corresponding check box in column D or E. Recommendations for optimization can be found in chapter 6.2.1 on page 92.

Remark

This column shows remarks in the form of footers that are described in detail in the status bar.

Area A

This column gives information about the area of each surface.

Mass G

This column indicates the mass of the respective surface.

Comment

The input fields in this column allow you to enter user-defined notes.

The buttons at the bottom right are reserved for the following functions:



Button	Function
	Jumps to the RFEM work window to adjust the view
	Allows you to pick a surface in the RFEM work window

Table 2.2: Buttons in window 1.3 Surfaces

2.1.4 Serviceability Data

The last input window manages the specifications for the serviceability limit state design. It is only available if you have selected load cases for the design in the tab *Serviceability Limit State* in window 1.1 (see chapter 2.1.1.2, page 11).

1.4 Serviceability Data

No.	A List of Surfaces	B Manual	C Reference Length L [mm]	D Cantilever	E Comment
1	51	<input type="checkbox"/>	4948.0	<input type="checkbox"/>	
2	53-58	<input type="checkbox"/>	6400.0	<input type="checkbox"/>	
3	61,62	<input type="checkbox"/>	450.0	<input type="checkbox"/>	
4	64	<input checked="" type="checkbox"/>	980.0	<input type="checkbox"/>	User-defined reference length
5					

Figure 2.13: Window 1.4 *Serviceability Data*

List of Surfaces

In this column, you enter the numbers of the surfaces that you want to design. You can also click [...] to select the surfaces graphically in the RFEM work window. Then, the program automatically enters the reference lengths in column C.

In case several surfaces are summarized in one input field, they should have the same geometrical conditions. The reference length L is preset as the maximum length of all boundary lines included in these surfaces.


Reference Length

Column C indicates the longest boundary lines in the respective surfaces. Here, the program refers to the lengths of single lines, that is continuous lines are not considered!

To adjust a reference length, select the *Manual* check box. Then you can access the input field L where you can enter the value manually. You can also click the button [▼] to select the value from the list or use the [...] function to determine it graphically in the RFEM work window.

B	C
Reference Length	Reference Length
Manual	L [mm]
<input checked="" type="checkbox"/>	4000.0 ▼

Distance Measure

 Pick two points to measure distance between them.

Node No. 24
Distance [mm]

Cancel

Figure 2.14: Dialog box to determine boundary points graphically

Manual corrections may be required, for example, for surfaces that are placed within other surfaces or share boundary lines.

Cantilever

To determine limit deformations correctly, it is also important to know if the surface is supported on all sides or if it is a cantilevered surface.

If a surface in column D is defined as *Cantilever*, higher limit values will be used for the design of the deflection. These values can be checked and, if necessary, adjusted in the *Serviceability* tab of the *Details* dialog box, (see Figure 2.16, page 24).

Details...

2.2 Calculation

Before you start the calculation by clicking [Calculation], it is recommended to check the design details. The corresponding dialog box can be accessed in all windows of the add-on module by clicking [Details].

Calculation

Details...

2.2.1 Detail Settings

The dialog box *Details* has the following tabs:

- Stresses
- Serviceability
- Options

2.2.1.1 Stresses




Figure 2.15: Dialog box *Details*, tab *Stresses*

Stresses to Calculate

The following stress types are displayed by default in windows 2.1 to 2.5:

- Shear stresses τ_{max}
- Principal stresses σ in direction of the principal axes 1 and 2 on the surface's top (-) and bottom side (+)
- Membrane stresses σ_m in direction of the principal axes 1 and 2
- Equivalent stress σ_{eqv}
- Membrane equivalent stress $\sigma_{eqv,m}$

The stress types to be displayed in the results windows can be defined in the dialog section *Stresses to Calculate*.

$\sigma_{x,+}$	Stress in direction of the local axis x on the positive side of the surface (that means the side in direction of the positive surface axis z) $\sigma_{x,+} = \frac{n_x}{d} + \frac{6 \cdot m_x}{d^2}$ where d : thickness of surface
$\sigma_{y,+}$	Stress in direction of local axis y on positive side of surface (that is the side in direction of positive surface axis z) $\sigma_{y,+} = \frac{n_y}{d} + \frac{6 \cdot m_y}{d^2}$
$\tau_{xy,+}$	Torsional stress on positive side of surface $\tau_{xy,+} = \frac{n_{xy}}{d} + \frac{6 \cdot m_{xy}}{d^2}$
$\sigma_{x,-}$	Stress in direction of the x-axis on the negative side of the surface $\sigma_{x,-} = \frac{n_x}{d} - \frac{6 \cdot m_x}{d^2}$
$\sigma_{y,-}$	Stress in direction of the y-axis on the negative side of the surface $\sigma_{y,-} = \frac{n_y}{d} - \frac{6 \cdot m_y}{d^2}$
$\tau_{xy,-}$	Torsional stress on the negative side of the surface $\tau_{xy,-} = \frac{n_{xy}}{d} - \frac{6 \cdot m_{xy}}{d^2}$
$\sigma_{x,m}$	Membrane stress due to axial force n_x $\sigma_{x,m} = \frac{n_x}{d}$
$\sigma_{y,m}$	Membrane stress due to axial force n_y $\sigma_{y,m} = \frac{n_y}{d}$
$\tau_{xy,m}$	Membrane stress due to shear flow n_{xy} $\tau_{xy,m} = \frac{n_{xy}}{d}$
$\sigma_{x,b}$	Stress due to bending moment m_x $\sigma_{x,b} = \frac{6 \cdot m_x}{d^2}$
$\sigma_{y,b}$	Stress due to bending moment m_y $\sigma_{y,b} = \frac{6 \cdot m_y}{d^2}$
τ_{xz}	Shear stress orthogonal to the surface in direction of the x-axis $\frac{3 \cdot v_x}{2 \cdot d}$
τ_{yz}	Shear stress orthogonal to the surface in direction of the y-axis $\frac{3 \cdot v_y}{2 \cdot d}$

τ_{\max}	Maximum shear stress perpendicular to the surface $\tau_{\max} = \sqrt{\tau_x^2 + \tau_y^2}$
$\sigma_{1,+}$	Stress in direction of the principal axis 1 on the positive side of the surface (that means the side in direction of the positive surface axis z) $\sigma_{1,+} = \frac{1}{2} \left(\sigma_{x,+} + \sigma_{y,+} + \sqrt{(\sigma_{x,+} - \sigma_{y,+})^2 + 4 \cdot \tau_{xy,+}^2} \right)$
$\sigma_{2,+}$	Stress in direction of the principal axis 2 on the positive side of the surface $\sigma_{2,+} = \frac{1}{2} \left(\sigma_{x,+} + \sigma_{y,+} - \sqrt{(\sigma_{x,+} - \sigma_{y,+})^2 + 4 \cdot \tau_{xy,+}^2} \right)$
α_+	Angle between local axis x (or y) and principal axis 1 (or 2) for stresses on the positive side of the surface $\alpha_+ = \frac{1}{2} \arctan 2 \left(\frac{\tau_{xy,+}}{\sigma_{x,+} - \sigma_{y,+}} \right) \in (-90^\circ, 90^\circ)$
$\sigma_{1,-}$	Stress in direction of the principal axis 1 on the negative side of the surface $\sigma_{1,-} = \frac{1}{2} \left(\sigma_{x,-} + \sigma_{y,-} + \sqrt{(\sigma_{x,-} - \sigma_{y,-})^2 + 4 \cdot \tau_{xy,-}^2} \right)$
$\sigma_{2,-}$	Stress in direction of the principal axis 2 on the negative side of the surface $\sigma_{2,-} = \frac{1}{2} \left(\sigma_{x,-} + \sigma_{y,-} - \sqrt{(\sigma_{x,-} - \sigma_{y,-})^2 + 4 \cdot \tau_{xy,-}^2} \right)$
α_-	Angle between local axis x (or y) and principal axis 1 (or 2) for stresses on the negative side of the surface $\alpha_- = \frac{1}{2} \arctan 2 \left(\frac{\tau_{xy,-}}{\sigma_{x,-} - \sigma_{y,-}} \right) \in (-90^\circ, 90^\circ)$
$\sigma_{1,m}$	Membrane stress due to axial force n_1 $\sigma_{1,m} = \frac{n_1}{d}$
$\sigma_{2,m}$	Membrane stress due to axial force n_2 $\sigma_{2,m} = \frac{n_2}{d}$
α_m	Angle between axis x and principal axis 1 (for axial force n_1) $\frac{1}{2} \left[\arctan \left(\frac{2 \cdot n_{xy}}{n_x - n_y} \right) \right]$
σ_{eqv}	Maximum equivalent stress as maximum of $\sigma_{\text{eqv},+}$ and $\sigma_{\text{eqv},-}$ (see below)
$\sigma_{\text{eqv},+}$	Equivalent stress on the positive side of the surface (that means the side in direction of the positive surface axis z) according to selected stress hypothesis (see Table 2.4 through Table 2.7)
$\sigma_{\text{eqv},-}$	Equivalent stress on the positive or negative side of the surface according to selected stress hypothesis (see Table 2.4 to Table 2.7)
$\sigma_{\text{eqv},m}$	Membrane equivalent stress according to selected stress hypothesis (see Table 2.4 through Table 2.7)

Table 2.3: Stresses

- Equivalent Stresses According to
- Von Mises, Huber, Hencky
Shape modification hypothesis
 - Tresca
Maximum shear stress criterion
 - Rankine, Lamé
Maximum principal stress criterion
 - Bach, Navier, St. Venant, Poncelet
Principal strain criterion

Equivalent Stresses According to

The equivalent stresses from the individual stress components can be determined according to four different approaches (see Figure 2.15, page 19).

Von Mises, Huber, Hencky

The stress hypothesis according to VON MISES is also known as *Shape modification hypothesis*. It is assumed that the material fails as soon as the shape modifying energy exceeds a certain limit. The shape modification energy represents the kind of energy that causes distortion or deformation of the element.

This approach is the best known and most frequently used equivalent stress hypothesis. It is the appropriate method for all materials that are not brittle. Therefore, it is widely used in steel building construction.

The equivalent stresses according to VON MISES for the plane state of stress have the following meanings:

$\sigma_{eqv,+}$	<p>Equivalent stress on the positive side of the surface (that means the side in direction of the positive surface axis z)</p> $\sigma_{eqv,+} = \sqrt{\sigma_{x,+}^2 + \sigma_{y,+}^2 - \sigma_{x,+} \cdot \sigma_{y,+} + 3 \cdot \tau_{xy,+}^2}$
$\sigma_{eqv,-}$	<p>Equivalent stress on the negative side of the surface</p> $\sigma_{eqv,-} = \sqrt{\sigma_{x,-}^2 + \sigma_{y,-}^2 - \sigma_{x,-} \cdot \sigma_{y,-} + 3 \cdot \tau_{xy,-}^2}$
$\sigma_{eqv,m}$	<p>Membrane equivalent stress as the maximum absolute value of</p> $\sigma_{eqv,m} = \frac{\sigma_{x,m} + \sigma_{y,m}}{2} + \sqrt{\left(\frac{\sigma_{x,m} - \sigma_{y,m}}{2}\right)^2 + \tau_{xy,m}^2} \text{ or}$ $\sigma_{eqv,m} = \frac{\sigma_{x,m} + \sigma_{y,m}}{2} - \sqrt{\left(\frac{\sigma_{x,m} - \sigma_{y,m}}{2}\right)^2 + \tau_{xy,m}^2} \text{ or}$ $\sigma_{eqv,m} = \sqrt{(\sigma_{x,m} - \sigma_{y,m})^2 + 4 \cdot \tau_{xy,m}^2}$ <p>where</p> $\sigma_{x,m} = \frac{n_x}{d}$ $\sigma_{y,m} = \frac{n_y}{d}$ $\tau_{xy,m} = \frac{n_{xy}}{d}$ <p style="text-align: right;">with d: thickness of surface</p>

Table 2.4: Equivalent stresses according to VON MISES, HUBER, HENCKY

Tresca, Coulomb, Mohr

The hypothesis according to TRESKA is also known as *Maximum shear stress criterion*. It is assumed that failure is caused by the maximum principal shear stress.

As this hypothesis is especially applicable for brittle materials, it is frequently used in mechanical engineering.

These equivalent stresses are determined according to the following equations:

$\sigma_{\text{eqv},+}$	<p>Equivalent stress on the positive side of the surface (that means the side in direction of the positive surface axis z)</p> $\sigma_{\text{eqv},+} = \sqrt{(\sigma_{x,+} - \sigma_{y,+})^2 + 4 \cdot \tau_{xy,+}^2}$
$\sigma_{\text{eqv},-}$	<p>Equivalent stress on the negative side of the surface</p> $\sigma_{\text{eqv},-} = \sqrt{(\sigma_{x,-} - \sigma_{y,-})^2 + 4 \cdot \tau_{xy,-}^2}$
$\sigma_{\text{eqv},m}$	<p>Membrane equivalent stress</p> $\sigma_{\text{eqv},m} = \sqrt{(\sigma_{x,m} - \sigma_{y,m})^2 + 4 \cdot \tau_{xy,m}^2}$

Table 2.5: Equivalent stresses according to TRESKA, COULOMB, MOHR

Rankine, Lamé

The equivalent stress hypothesis according to RANKINE is also known as the *Maximum principal stress criterion*. It is assumed that failure is caused by the maximum principal stress.

These equivalent stresses are determined according to the following equations:

$\sigma_{\text{eqv},+}$	<p>Maximum absolute value of equivalent stress on the positive side of the surface</p> $\sigma_{\text{eqv},+} = \frac{1}{2}(\sigma_{x,+} + \sigma_{y,+}) \pm \frac{1}{2}\sqrt{(\sigma_{x,+} - \sigma_{y,+})^2 + 4 \cdot \tau_{xy,+}^2}$
$\sigma_{\text{eqv},-}$	<p>Maximum absolute value of equivalent stress on the negative side of the surface</p> $\sigma_{\text{eqv},-} = \frac{1}{2}(\sigma_{x,-} + \sigma_{y,-}) \pm \frac{1}{2}\sqrt{(\sigma_{x,-} - \sigma_{y,-})^2 + 4 \cdot \tau_{xy,-}^2}$
$\sigma_{\text{eqv},m}$	<p>Maximum absolute value of membrane equivalent stress</p> $\sigma_{\text{eqv},m} = \frac{1}{2}(\sigma_{x,m} + \sigma_{y,m}) \pm \frac{1}{2}\sqrt{(\sigma_{x,m} - \sigma_{y,m})^2 + 4 \cdot \tau_{xy,m}^2}$

Table 2.6: Equivalent stresses according to RANKINE, LAMÉ

Bach, Navier, St. Venant, Poncelet

The equivalent stress hypothesis according to BACH is also known as the *Principal strain criterion*. It is assumed that failure occurs in the direction of the maximum strain. This approach is similar to the stress determination according to RANKINE described above. Here, the principal strain is used instead of the principal stress.

The equivalent stresses are determined according to the following equations:

$\sigma_{\text{eqv},+}$	Maximum absolute value of equivalent stress on the positive side of the surface $\sigma_{\text{eqv},+} = \frac{1-\nu}{2}(\sigma_{x,+} + \sigma_{y,+}) \pm \frac{1+\nu}{2} \sqrt{(\sigma_{x,+} - \sigma_{y,+})^2 + 4 \cdot \tau_{xy,+}^2}$ where ν : Poisson's ratio of material
$\sigma_{\text{eqv},-}$	Maximum absolute value of equivalent stress on the negative side of the surface $\sigma_{\text{eqv},-} = \frac{1-\nu}{2}(\sigma_{x,-} + \sigma_{y,-}) \pm \frac{1+\nu}{2} \sqrt{(\sigma_{x,-} - \sigma_{y,-})^2 + 4 \cdot \tau_{xy,-}^2}$
$\sigma_{\text{eqv},m}$	Maximum absolute value of membrane equivalent stress $\sigma_{\text{eqv},m} = \frac{1-\nu}{2}(\sigma_{x,m} + \sigma_{y,m}) \pm \frac{1+\nu}{2} \sqrt{(\sigma_{x,m} - \sigma_{y,m})^2 + 4 \cdot \tau_{xy,m}^2}$

Table 2.7: Equivalent stresses according to BACH, NAVIER, ST. VENANT, POCELET

2.2.1.2 Serviceability




Figure 2.16: Dialog box *Details*, tab *Serviceability*

The six input fields are used to manage the *Serviceability Limits* of the allowable deflections. It is possible to enter specific settings for the different action combinations –

- Characteristic
- Frequent
- Quasi-permanent

– as well as for both-sided and one-sided supported surfaces.

The classification of action combinations is determined in the *Serviceability Limit State* tab of table 1.1 *General Data* (see chapter 2.1.1.2, page 11).

The reference lengths L are defined for each surface in window 1.4 *Serviceability Data* (see chapter 2.1.4, page 18).

2.2.1.3 Options




Figure 2.17: Dialog box *Details*, tab *Options*

Analysis Method for Result Combinations

In this dialog section, you define how the design internal forces of result combinations are to be determined. The *Mixed Method* is preset by default: Before the design is carried out, the program checks if the *Enumeration Method* is more effective than the *Envelope Method* or vice versa.

Enumeration Method

The module evaluates the internal forces from RFEM line by line to superimpose them appropriately. This is the approach that comprehends all combination possibilities accurately.

The disadvantage of this method is that the number of combinations for the analysis is growing exponentially with the number of load cases when processing the data line by line: For a result combination with n load cases, 2^n combination possibilities exist.

Therefore, the more load cases the combination contains, the more time is required for the stress design. In the results, however, all possible combinations are included.

Envelope Method

The module considers only the extreme values of the internal forces of each load case to combine them subsequently. In this way, this approach might not comprehend the most unfavorable combinations that would be included in a line by line process. However, the computing time for a relatively large number of load cases in a result combination is quite acceptable when this kind of method is used.

As only the maximum values are analyzed, the designs may be incorrect. Combinations with load cases whose effective directions tend to be orthogonal must be handled carefully. In such cases, a calculation according to the enumeration method is recommended to check the results.

Mixed Method

Before the design is carried out, the module checks how many combinations with the load cases exist. If the result combination contains, for example, seven load cases, then $2^7 = 128$ combinations of internal forces are possible (see *Enumeration Method*). As this number is higher than the preset number of 100 possibilities, the design will be carried out according to the *Envelope Method*.

In this field, you can define the upper limit of the combination possibilities for the design according to the accurate enumeration method.

Thus, the *Mixed Method* represents a compromise between result accuracy and design velocity.

Stresses from internal forces

For this method, the stresses are determined directly from the surface internal forces of the result combination. The internal forces are taken from the RFEM result windows 4.14 and 4.15. In this way, you can check for example result combinations created in the add-on module RF-STAGES, as this module does not calculate internal forces of load cases.

Results in

By default, stresses and displacements are displayed in all *FE mesh points*. As an alternative, the results output is available in the user-defined *Grid points* defined in the surface properties in RFEM (see RFEM manual, chapter 8.12).

FE mesh points Grid points



At the bottom of the window, you find two option fields. You can choose whether the result data will be shown in *FE mesh points* or *Grid points*. The results of the FE mesh points are directly determined by the analysis core, while the grid points results are determined by interpolating the FE points results.

Especially for small surfaces, the default mesh size of 0,5 m may produce only few results grid points (or even only one in the grid origin). In these cases, the maximum values are often not considered in the output windows because the results grid is too coarse. Then, the spacing of grid points may be adjusted in RFEM to the surface size in order to generate more grid points.

Optimization of Surface Thicknesses

The optimization is targeted on the maximum stress ratio of 100 %. If necessary, you can specify a different limit value in this input field.

Display Result Tables

In this dialog section, you can select the results tables, including parts list that you want to be displayed. The tables are described in chapter 3.3 *Results*.

The tables 2.5 *Stresses in All Points* and 2.6 *Stress Ranges* are inactive by default. Now, you can check the results in all FE mesh and grid points as well as the stress ranges for the fatigue design in the tables.

Distribution of Internal Forces

The FE analysis determines the results for each FE mesh node. However, for a continuous distribution of the stresses or stress ratios in the graphic, it is necessary to smooth the results. An example can be found in the RFEM manual, chapter 9.7.1.

The smoothing option *Continuous within surfaces* is preset, as this provides the best graphical results in most cases. This means the values of the FE nodes are averaged. Averaging stops on the surface boundary, thus potentially resulting in discontinuities between adjacent surfaces.

For plastic material models, the option *Constant on elements* is recommended: The values of the FE nodes are averaged and the result is shown in the middle of the elements. The distribution is constant in every element.

Apply smoothed internal forces in the defined smooth ranges

Usually, the RFEM internal forces smoothed by surface are used for design.

If you select the check box in this dialog section, the internal forces of the user-defined smooth ranges in RFEM will be used for design. The smoothed results can help reduce singularities and take into account local redistribution effects in the model.

The smooth ranges are described in the RFEM manual, chapter 9.7.3.

2.2.2 Start Calculation

Calculation

To start the calculation, click the [Calculation] button, which is available in all input windows.

RF-STEEL Surfaces searches for the results of the load cases as well as the load and result combinations you want to design. If they cannot be found, the program starts the RFEM calculation to determine the design relevant internal forces.

You can also start the calculation in the RFEM user interface: The dialog box *To Calculate* (menu *Calculate* → *To Calculate*) lists design cases of the add-on modules like load cases and load combinations.




Figure 2.18: Dialog box *To Calculate*

If the RF-STEEL design cases are missing in the *Not Calculated* list, select *All* or *Add-on Modules* in the drop-down list at the list's end.

Click [▶] to transfer the selected RF-STEEL cases to the list on the right. Click [OK] to start the calculation.

To calculate a design case directly, use the list in the toolbar. Select the RF-STEEL Surfaces design case in the toolbar list and click [Show Results].





Figure 2.19: Direct calculation of a RF-STEEL Surfaces design case in RFEM

Subsequently, you can observe the design process in a separate dialog box.



2.3 Results

Window 2.1 *Stresses by Load Case* is displayed immediately after the calculation.

Load Case	Surface No.	FE Mesh Point No.	X	Y	Z	Symbol	Stress [N/mm ²]	Limit	Stress Ratio [-]
CO5	53	3	-3225.0	3225.0	0.0	σ_{max}	5.5	144.3	0.04
	53	597	-3225.0	3400.0	0.0	σ_{1-}	155.7	250.0	0.62
	53	3	-3225.0	3225.0	0.0	σ_{2-}	-150.7	250.0	0.60
	53	3	-3225.0	3225.0	0.0	σ_{1-}	230.3	250.0	0.92
	53	597	-3225.0	3400.0	0.0	σ_{2-}	-169.1	250.0	0.68
	53	375	1575.0	3400.0	0.0	$\sigma_{1,m}$	65.4	250.0	0.26
	55	141	3200.0	-3200.0	0.0	$\sigma_{2,m}$	-62.4	240.9	0.26
	53	3	-3225.0	3225.0	0.0	σ_{eqv}	212.1	250.0	0.85
	55	141	3200.0	-3200.0	0.0	$\sigma_{eqv,m}$	72.1	240.9	0.30
	CO6	53	3	-3225.0	3225.0	0.0	σ_{max}	3.0	144.3
53		373	1575.0	3225.0	0.0	σ_{1-}	104.9	250.0	0.42
53		3	-3225.0	3225.0	0.0	σ_{2-}	-84.8	250.0	0.34
53		3	-3225.0	3225.0	0.0	σ_{1-}	129.6	250.0	0.52
53		373	1575.0	3225.0	0.0	σ_{2-}	-97.4	250.0	0.39
53		375	1575.0	3400.0	0.0	$\sigma_{1,m}$	33.5	250.0	0.13
53		307	-3075.0	3400.0	0.0	$\sigma_{2,m}$	-17.9	250.0	0.07
53		3	-3225.0	3225.0	0.0	σ_{eqv}	120.9	250.0	0.48
53		371	1425.0	3400.0	0.0	$\sigma_{eqv,m}$	31.2	250.0	0.12
Maximum Stresses									
53	3	-3225.0	3225.0	0.0	σ_{max}	5.5	144.3	0.04	
53	597	-3225.0	3400.0	0.0	σ_{1-}	155.7	250.0	0.62	
53	3	-3225.0	3225.0	0.0	σ_{2-}	-150.7	250.0	0.60	
53	3	-3225.0	3225.0	0.0	σ_{1-}	230.3	250.0	0.92	
53	597	-3225.0	3400.0	0.0	σ_{2-}	-169.1	250.0	0.68	
53	375	1575.0	3400.0	0.0	$\sigma_{1,m}$	65.4	250.0	0.26	
55	141	3200.0	-3200.0	0.0	$\sigma_{2,m}$	-62.4	240.9	0.26	
53	3	-3225.0	3225.0	0.0	σ_{eqv}	212.1	250.0	0.85	
55	141	3200.0	-3200.0	0.0	$\sigma_{eqv,m}$	72.1	240.9	0.30	

Figure 2.20: Results window

The stress designs are shown in the results windows 2.1 to 2.6, sorted by different criteria.

Window 3.1 informs you about the serviceability limit state designs. The last results window 4.1 contains a parts list of the designed surfaces.



Every window can be selected by clicking the corresponding entry in the navigator. To open the previous or next input window, use the buttons shown on the left. You can also use the function keys to select the previous [F3] or next [F2] window.

FE mesh points Grid points

There are two option fields at the bottom of the windows. They control whether to show the results in *FE mesh points* or *Grid points*. The results of the FE mesh points are directly determined by the analysis core, while the grid points results are determined by interpolating the FE points results.

OK

Click [OK] to save the results. Exit RF-STEEL Surfaces and return to the main program.

Chapter 2.3 *Results* describes the different results windows one by one. Evaluating and checking results is described in chapter 4 *Results Evaluation*, page 71 ff.

2.3.1 Stresses by Load Case

This window offers a summary, sorted by load cases as well as load and result combinations, of the maximum stress ratios for the ultimate limit state.



The buttons are described in detail in chapter 4 *Results Evaluation* on page 71.

2.1 Stresses by Load Case

Loading	Surface No.	FE Mesh Point No.	Point Coordinates [mm]			Symbol	Stress [N/mm ²]		Stress Ratio [-]	J
			X	Y	Z		Existing	Limit		
CO5										
	53	3	-3225.0	3225.0	0.0	τ_{max}	5.5	144.3	0.04	
	53	597	-3225.0	3400.0	0.0	$\sigma_{1,+}$	155.7	250.0	0.62	
	53	3	-3225.0	3225.0	0.0	$\sigma_{2,+}$	-150.7	250.0	0.60	
	53	3	-3225.0	3225.0	0.0	$\sigma_{1,-}$	230.3	250.0	0.92	
	53	597	-3225.0	3400.0	0.0	$\sigma_{2,-}$	-169.1	250.0	0.68	
	53	375	1575.0	3400.0	0.0	$\sigma_{1,m}$	65.4	250.0	0.26	
	55	141	3200.0	-3200.0	0.0	$\sigma_{2,m}$	-62.4	240.9	0.26	
	53	3	-3225.0	3225.0	0.0	σ_{eqv}	212.1	250.0	0.85	
	55	141	3200.0	-3200.0	0.0	$\sigma_{eqv,m}$	72.1	240.9	0.30	
CO6										
	53	3	-3225.0	3225.0	0.0	τ_{max}	3.0	144.3	0.02	
	53	373	1575.0	3225.0	0.0	$\sigma_{1,+}$	104.9	250.0	0.42	
	53	3	-3225.0	3225.0	0.0	$\sigma_{2,+}$	-84.8	250.0	0.34	
	53	3	-3225.0	3225.0	0.0	$\sigma_{1,-}$	129.6	250.0	0.52	
	53	373	1575.0	3225.0	0.0	$\sigma_{2,-}$	-97.4	250.0	0.39	
	53	375	1575.0	3400.0	0.0	$\sigma_{1,m}$	33.5	250.0	0.13	
	53	307	-3075.0	3400.0	0.0	$\sigma_{2,m}$	-17.9	250.0	0.07	
	53	3	-3225.0	3225.0	0.0	σ_{eqv}	120.9	250.0	0.48	
	53	371	1425.0	3400.0	0.0	$\sigma_{eqv,m}$	31.2	250.0	0.12	
- Maximum Stresses										
	53	3	-3225.0	3225.0	0.0	τ_{max}	5.5	144.3	0.04	
	53	597	-3225.0	3400.0	0.0	$\sigma_{1,+}$	155.7	250.0	0.62	
	53	3	-3225.0	3225.0	0.0	$\sigma_{2,+}$	-150.7	250.0	0.60	
	53	3	-3225.0	3225.0	0.0	$\sigma_{1,-}$	230.3	250.0	0.92	
	53	597	-3225.0	3400.0	0.0	$\sigma_{2,-}$	-169.1	250.0	0.68	
	53	375	1575.0	3400.0	0.0	$\sigma_{1,m}$	65.4	250.0	0.26	
	55	141	3200.0	-3200.0	0.0	$\sigma_{2,m}$	-62.4	240.9	0.26	
	53	3	-3225.0	3225.0	0.0	σ_{eqv}	212.1	250.0	0.85	
	55	141	3200.0	-3200.0	0.0	$\sigma_{eqv,m}$	72.1	240.9	0.30	

FE mesh points
 Grid points
 Max: 0.92 ≤ 1

Figure 2.21: Window 2.1 *Stresses by Load Case*

Surface No.

This column shows the numbers of the surfaces containing the governing points.

FE Mesh Point No. / Grid Point No.

The maximum ratio was determined for the FE mesh or grid points indicated in this column. Column F *Symbol* shows the stress type.

The FE mesh points *N* are created automatically. The grid points *R*, however, can be controlled in RFEM, where you can set user-defined result grids. This function is described in detail in the RFEM manual, chapter 8.12. The tab *Options* in the dialog box *Details* controls whether the results are displayed in the grid or FE mesh points (see chapter 2.2.1.3, page 26).


Point Coordinates X/Y/Z


The three columns contain the coordinates of the governing FE mesh or grid points.

Symbol

The following stress ratios due to these stresses are displayed by default:

- Shear stress τ_{max}
- Principal stress σ in direction of the principal axes on the surface's top and bottom side
- Membrane stress σ_m in direction of the principal axes
- Equivalent stress σ_{eqv}
- Membrane equivalent stress $\sigma_{eqv,m}$





The indices of the normal stresses σ , shear stresses τ , and equivalent stresses σ_{eqv} have the following meanings:

Symbol	Meaning
x	Direction of the local surface axis x
y	Direction of the local surface axis y
1	Direction of the principal axis 1
2	Direction of the principal axis 2
+	Positive surface side (side in direction of the positive local surface axis z)
-	Negative surface side (side in the opposite direction of the positive surface axis z)
m	Stress due to membrane force (axial force)
b	Stress due to bending moment

Table 2.8: Symbols of stresses



The stress types to be displayed in the results window can be defined in the dialog box *Details*, tab *Stresses* (see Figure 2.15, page 19). The dialog box can also be opened by clicking the button shown on the left. It can be found at the bottom of the window.

The positive surface side is always defined in direction of the positive local axis z of a surface, regardless of the orientation of the global axis Z. In the RFEM graphic, the xyz coordinate systems are shown as soon as the mouse pointer rests on a surface. You can also hide or display the axes by using the context menu of a surface (right-click it).





Figure 2.22: RFEM context menu of surface




To display the surface sides in different colors, select *Colors in Rendering According to* → *+/- z Surface sides* in the *Display* navigator (see Figure on the left).

Stress - Existing

This column displays the extreme values of the existing stresses determined according to the equations in Table 2.3 to Table 2.7 (see page 20 to 24).

For each stress type, the program calculates the maximum (positive) and minimum (negative) stress values to compare their results subsequently. The value that is higher than the other one will appear in column G.

The equivalent stresses σ_{eqv} are determined according to the stress criterion specified in the *Details* dialog box, tab *Stresses* (see Figure 2.15, page 19).




Stress - Limit

This column shows the limit stresses of window 1.2, column E to H (see chapter 2.1.2, page 12). In particular, they are the following:

- Limit normal stress σ_x as the allowable stress for actions due to bending and membrane force
- Limit shear stress τ as the allowable shear stress due to shear and torsion
- Limit equivalent stress σ_{eqv} as the allowable equivalent stress for the simultaneous effect of normal and shear stresses
- Limit membrane equivalent stress $\sigma_{\text{eqv,m}}$ as the allowable equivalent stress due to membrane stresses

Stress Ratio

The last column shows the quotient from the existing and the limiting stress. If the limit stress is not exceeded, the ratio is less than or equal to 1 and the stress design was carried out successfully.



The length of the colored scales represents the respective stress ratios.

For stress designs, as described for example in DIN 18800 part 1, el. (747), the program determines the quotient from the existing and the limit stress.

$$\frac{\sigma}{\sigma_{R,d}} \leq 1$$

Equation 2.5: Design condition for normal stresses

$$\frac{\tau}{\tau_{R,d}} \leq 1$$

Equation 2.6: Design condition for shear stresses

$$\frac{\sigma_{\text{eqv}}}{\sigma_{R,d}} \leq 1$$

Equation 2.7: Design condition for equivalent stresses

2.3.2 Stresses by Material

2.2 Stresses by Material

Material No.	A Surface No.	B FE Mesh Point No.	C Point Coordinates [mm] X	D Y	E Z	F Loading	G Symbol	H Stress [N/mm ²] Existing	I Limit	J Stress Ratio [-]	K
1	Baustahl	S 275 JR									
	53	3	-3225.0	3225.0	0.0	CO5	τ_{max}	5.5	144.3	0.04	
	53	597	-3225.0	3400.0	0.0	CO5	$\sigma_{1,+}$	155.7	250.0	0.62	
	53	3	-3225.0	3225.0	0.0	CO5	$\sigma_{2,+}$	-150.7	250.0	0.60	
	53	3	-3225.0	3225.0	0.0	CO5	$\sigma_{1,-}$	230.3	250.0	0.92	
	53	597	-3225.0	3400.0	0.0	CO5	$\sigma_{2,-}$	-169.1	250.0	0.68	
	53	375	1575.0	3400.0	0.0	CO5	$\sigma_{1,m}$	65.4	250.0	0.26	
	55	141	3200.0	-3200.0	0.0	CO5	$\sigma_{2,m}$	-62.4	240.9	0.26	
	53	3	-3225.0	3225.0	0.0	CO5	σ_{eqv}	212.1	250.0	0.85	
	55	141	3200.0	-3200.0	0.0	CO5	$\sigma_{eqv,m}$	72.1	240.9	0.30	

FE mesh points Grid points Max: 0.92 ≤ 1

Figure 2.23: Window 2.2 Stresses by Material

This window lists the maximum stress ratios sorted by materials. These columns are described in detail in chapter 2.3.1.

2.3.3 Stresses by Surface

2.3 Stresses by Surface

Surface No.	A FE Mesh Point No.	B Point Coordinates [mm] X	C Y	D Z	E Loading	F Symbol	G Stress [N/mm ²] Existing	H Limit	I Stress Ratio [-]	J	
51	Material: Baustahl S 275 JR - Thickness d: 6.0 mm										
	2123	-2995.8	973.4	-24528.0	CO5	τ_{max}	0.0	144.3	0.00		
	123	-3150.0	0.0	-24528.0	CO5	$\sigma_{1,+}$	2.0	250.0	0.01		
	123	-3150.0	0.0	-24528.0	CO5	$\sigma_{2,+}$	-2.4	250.0	0.01		
	2124	-3111.2	492.8	-24528.0	CO5	$\sigma_{1,-}$	-3.1	250.0	0.01		
	2123	-2995.8	973.4	-24528.0	CO5	$\sigma_{2,-}$	-3.3	250.0	0.01		
	119	0.0	3150.0	-24528.0	CO5	$\sigma_{1,m}$	1.6	250.0	0.01		
	2123	-2995.8	973.4	-24528.0	CO5	$\sigma_{2,m}$	-2.8	250.0	0.01		
	123	-3150.0	0.0	-24528.0	CO5	σ_{eqv}	3.8	250.0	0.02		
	2123	-2995.8	973.4	-24528.0	CO5	$\sigma_{eqv,m}$	2.5	250.0	0.01		
52	Material: Baustahl S 275 JR - Thickness d: 6.0 mm										
	2179	-492.8	-3111.2	-24528.0	CO5	τ_{max}	0.0	144.3	0.00		
	117	0.0	-3150.0	-24528.0	CO5	$\sigma_{1,+}$	5.5	250.0	0.02		
	117	0.0	-3150.0	-24528.0	CO5	$\sigma_{2,+}$	-5.1	250.0	0.02		
	117	0.0	-3150.0	-24528.0	CO5	$\sigma_{1,-}$	6.7	250.0	0.03		
	117	0.0	-3150.0	-24528.0	CO5	$\sigma_{2,-}$	5.2	250.0	0.02		
	117	0.0	-3150.0	-24528.0	CO5	$\sigma_{1,m}$	5.9	250.0	0.02		
	123	-3150.0	0.0	-24528.0	CO5	$\sigma_{2,m}$	-2.7	250.0	0.01		
	117	0.0	-3150.0	-24528.0	CO5	σ_{eqv}	9.2	250.0	0.04		
	117	0.0	-3150.0	-24528.0	CO5	$\sigma_{eqv,m}$	5.8	250.0	0.02		
53	Material: Baustahl S 275 JR - Thickness d: 6.0 mm										
	3	-3225.0	3225.0	0.0	CO5	τ_{max}	5.5	144.3	0.04		
	597	-3225.0	3400.0	0.0	CO5	$\sigma_{1,+}$	155.7	250.0	0.62		
	3	-3225.0	3225.0	0.0	CO5	$\sigma_{2,+}$	-150.7	250.0	0.60		
	3	-3225.0	3225.0	0.0	CO5	$\sigma_{1,-}$	230.3	250.0	0.92		
	597	-3225.0	3400.0	0.0	CO5	$\sigma_{2,-}$	-169.1	250.0	0.68		
	375	1575.0	3400.0	0.0	CO5	$\sigma_{1,m}$	65.4	250.0	0.26		
	307	-3075.0	3400.0	0.0	CO5	$\sigma_{2,m}$	-32.6	250.0	0.13		
	3	-3225.0	3225.0	0.0	CO5	σ_{eqv}	212.1	250.0	0.85		
	371	1425.0	3400.0	0.0	CO5	$\sigma_{eqv,m}$	60.8	250.0	0.24		
54	Material: Baustahl S 275 JR - Thickness d: 30.0 mm										

FE mesh points Grid points Max: 0.92 ≤ 1

Figure 2.24: Window 2.3 Stresses by Surface

This results window lists the maximum stress ratios that exist for each designed surface.

2.3.4 Stresses by Line

2.4 Stresses by Line

Line No.	FE Mesh Point No.	Point Coordinates [mm]			Loading	Symbol	Stress [N/mm ²]		Stress Ratio [-]
		X	Y	Z			Existing	Limit	
1 Node No.: 4,46									
46	3225.0	3200.0	0.0	CO5	τ_{max}	0.6	139.1	0.00	
46	3225.0	3200.0	0.0	CO6	$\sigma_{1,+}$	2.0	240.9	0.01	
46	3225.0	3200.0	0.0	CO5	$\sigma_{2,+}$	-2.8	240.9	0.01	
46	3225.0	3200.0	0.0	CO5	$\sigma_{1,-}$	4.3	240.9	0.02	
46	3225.0	3200.0	0.0	CO5	$\sigma_{2,-}$	-3.8	240.9	0.02	
4	3225.0	3225.0	0.0	CO6	$\sigma_{1,m}$	2.3	240.9	0.01	
46	3225.0	3200.0	0.0	CO5	$\sigma_{2,m}$	-2.5	240.9	0.01	
46	3225.0	3200.0	0.0	CO5	σ_{eqv}	7.0	240.9	0.03	
46	3225.0	3200.0	0.0	CO6	$\sigma_{eqv,m}$	3.3	240.9	0.01	
2 Node No.: 3,305									
3	-3225.0	3225.0	0.0	CO5	τ_{max}	5.5	144.3	0.04	
305	-3075.0	3225.0	0.0	CO5	$\sigma_{1,+}$	75.2	250.0	0.30	
3	-3225.0	3225.0	0.0	CO5	$\sigma_{2,+}$	-150.7	250.0	0.60	
3	-3225.0	3225.0	0.0	CO5	$\sigma_{1,-}$	230.3	250.0	0.92	
3	-3225.0	3225.0	0.0	CO5	$\sigma_{2,-}$	51.1	250.0	0.20	
3	-3225.0	3225.0	0.0	CO5	$\sigma_{1,m}$	40.7	250.0	0.16	
305	-3075.0	3225.0	0.0	CO5	$\sigma_{2,m}$	-10.2	250.0	0.04	
3	-3225.0	3225.0	0.0	CO5	σ_{eqv}	212.1	250.0	0.85	
3	-3225.0	3225.0	0.0	CO5	$\sigma_{eqv,m}$	44.6	250.0	0.18	
3 Node No.: 3,138									
138	-3225.0	3200.0	0.0	CO5	τ_{max}	1.4	139.1	0.01	
138	-3225.0	3200.0	0.0	CO5	$\sigma_{1,+}$	12.2	240.9	0.05	
138	-3225.0	3200.0	0.0	CO5	$\sigma_{2,+}$	-13.4	240.9	0.06	
3	-3225.0	3225.0	0.0	CO5	$\sigma_{1,-}$	11.6	240.9	0.05	
3	-3225.0	3225.0	0.0	CO5	$\sigma_{2,-}$	-6.3	240.9	0.03	
138	-3225.0	3200.0	0.0	CO5	$\sigma_{1,m}$	9.5	240.9	0.04	
3	-3225.0	3225.0	0.0	CO5	$\sigma_{2,m}$	-7.0	240.9	0.03	
138	-3225.0	3200.0	0.0	CO5	σ_{eqv}	22.2	240.9	0.09	
138	-3225.0	3200.0	0.0	CO5	$\sigma_{eqv,m}$	14.2	240.9	0.06	
4 Node No.: 46,50									

FE mesh points
 Grid points
 Max: 0.92 ≤ 1

Figure 2.25: Window 2.4 Stresses by Line

The maximum stresses are displayed for all lines that are available in the designed surfaces. The results are sorted by line numbers.

2.3.5 Stresses in All Points

2.5 Stresses in All Points

FE Mesh Point No.	Surface No.	Line No.	Node No.	Point Coordinates [mm]			Loading	Symbol	Stress [N/mm ²]		Stress Ratio [-]
				X	Y	Z			Existing	Limit	
119	51	39, 142	119	0.0	3150.0	-24528.0	CO5	τ_{max}	0.0	144.3	0.00
								$\sigma_{1,+}$	1.3	250.0	0.01
								$\sigma_{2,+}$	-1.0	250.0	0.00
								$\sigma_{1,-}$	1.9	250.0	0.01
								$\sigma_{2,-}$	0.5	250.0	0.00
								$\sigma_{1,m}$	1.6	250.0	0.01
								$\sigma_{2,m}$	-0.2	250.0	0.00
								σ_{eqv}	2.0	250.0	0.01
								$\sigma_{eqv,m}$	1.7	250.0	0.01
								119	51	39, 142	119
$\sigma_{1,+}$	0.3	250.0	0.00								
$\sigma_{2,+}$	-0.5	250.0	0.00								
$\sigma_{1,-}$	0.3	250.0	0.00								
$\sigma_{2,-}$	-0.2	250.0	0.00								
$\sigma_{1,m}$	0.3	250.0	0.00								
$\sigma_{2,m}$	-0.4	250.0	0.00								
σ_{eqv}	0.7	250.0	0.00								
$\sigma_{eqv,m}$	0.6	250.0	0.00								
122	51	142	122	-2227.4	2227.4	-24528.0	CO5				
								$\sigma_{1,+}$	1.0	250.0	0.00
								$\sigma_{2,+}$	-1.3	250.0	0.01
								$\sigma_{1,-}$	-1.6	250.0	0.01
								$\sigma_{2,-}$	-2.6	250.0	0.01
								$\sigma_{1,m}$	-0.5	250.0	0.00
								$\sigma_{2,m}$	-1.8	250.0	0.01
								σ_{eqv}	2.3	250.0	0.01
								$\sigma_{eqv,m}$	1.6	250.0	0.01
								122	51	142	122
$\sigma_{1,+}$	0.2	250.0	0.00								

Max: 0.92 ≤ 1

Figure 2.26: Window 2.5 Stresses in All Points

Details...

Details...


This results window is inactive by default because the program must manage a considerable amount of data when complex models are analyzed. For a specific evaluation, however, it is possible to activate the window in the dialog box *Details*, tab *Options* (see Figure 2.17, page 25).

The window shows the stresses and stress ratios for each FE mesh or grid point that is available in the designed surfaces. The dialog box *Details*, tab *Options* (see Figure 2.17, page 25) determines whether the results should be displayed by FE mesh nodes or user-defined grid points.

The columns of this table are described in detail in chapter 2.3.1, page 30f.

Filtering results columns

For a clearer overview of this table, you can sort the results by surface, line, and node numbers as well as loads. The list below the columns allows you to sort the results by object numbers. Surfaces, lines, and nodes can also be specified graphically by clicking [^] in the RFEM work window.



Filter function

2.3.6 Stress Ranges

2.6 Stress Ranges

FE Mesh Point No.	Element No.	Surface No.	Line No.	Node No.	Point Coordinates [mm]			Stress [N/mm ²]					
					X	Y	Z	Symbol	Loading	Maximum	Loading	Minimum	Range
119	2689	51	39, 142	119	0.0	3150.0	-24528.	t _{max}	C05	0.0	-	-	-
								σ _{1,+}	C05	1.3	-	-	-
								σ _{2,+}	-	-	C05	-1.0	-
								σ _{1,-}	C05	1.9	-	-	-
								σ _{2,-}	C05	0.5	-	-	-
								σ _{1,m}	C05	1.6	-	-	-
								σ _{2,m}	-	-	C05	-0.2	-
								σ _{eqv}	C05	2.0	-	-	-
								σ _{eqv,r}	C05	1.7	-	-	-
119	2689	51	39, 142	119	0.0	3150.0	-24528.	t _{max}	C06	0.0	-	-	-
								σ _{1,+}	C06	0.3	-	-	-
								σ _{2,+}	-	-	C06	-0.5	-
								σ _{1,-}	C06	0.3	-	-	-
								σ _{2,-}	-	-	C06	-0.2	-
								σ _{1,m}	C06	0.3	-	-	-
								σ _{2,m}	-	-	C06	-0.4	-
								σ _{eqv}	C06	0.7	-	-	-
								σ _{eqv,r}	C06	0.6	-	-	-
122	2693	51	142	122	-2227.4	2227.4	-24528.	t _{max}	C05	0.0	-	-	-
								σ _{1,+}	C05	1.0	-	-	-
								σ _{2,+}	-	-	C05	-1.3	-
								σ _{1,-}	-	-	C05	-1.6	-
								σ _{2,-}	-	-	C05	-2.6	-
								σ _{1,m}	-	-	C05	-0.5	-
								σ _{2,m}	-	-	C05	-1.8	-
								σ _{eqv}	C05	2.3	-	-	-
								σ _{eqv,r}	C05	1.6	-	-	-
122	2694	51	142	122	-2227.4	2227.4	-24528.	t _{max}	C05	0.0	-	-	-
								σ _{1,+}	C05	1.0	-	-	-

Figure 2.27: Window 2.6 .Stress Ranges

Details...

This results window is inactive by default. However, it can be activated in the *Details* dialog box, tab *Options* (see Figure 2.17, page 25).

Details...

The stress ranges of the stress intensities are required for fatigue designs when analyzing the fatigue behavior. This window displays the stress differences for each FE mesh or grid point of the designed surfaces.

To specify the stress types to be displayed in the results window, use the *Details* dialog box, tab *Stresses* (see Figure 2.15, page 19). You can also open this dialog box by using the buttons shown on the left. They are located at the bottom of the window.

The table results can be sorted by surface, line, and node numbers. To do this, use the lists below the columns or select the items graphically by using [↵].

Details on columns A to H can be found in chapter 2.3.1 on page 30

Loading

Columns I and K show the relevant load cases, load combinations, and result combinations that bear the maximum and minimum stresses. In these two columns, all actions that have been set for the ultimate limit state design in window 1.1 *General Data* are considered.

Stress Maximum / Minimum

Column J lists the maximum stress values that are available for each stress type. Column L lists the minimum stress values. The *Maximum* is represented by the positive extreme values, the *Minimum* is represented by the negative ones.

Range

The values displayed in this column represent the range of stresses that result from the extreme values in column I and K.

2.3.7 Displacements

The results of the deformation analyses are only displayed when you have selected at least one action for the design in window 1.1 *General Data*, tab *Serviceability Limit State* (see chapter 2.1.1.2, page 11). Furthermore, it is necessary to define surface reference lengths for the limit deformations in window 1.4 *Serviceability Data* (see chapter 2.1.4, page 18).

Window 3.1 displays the maximum displacements due to the serviceability load cases or combinations and compares them with the allowable deformations. The results are listed by surface numbers.

3.1 Displacements

Surface No.	A		B			C			D			E		F		G		H		I		J	
	FE Mesh Point No.	X	Y	Z	Loading	Combination	Displacements [mm] u_z	Limit u_z	Ratio [-]														
51	127	0.0	3150.0	-27110.0	LC1	CH	0.8	16.5	0.05														
63	349	-225.0	3225.0	0.0	LC1	CH	0.1	21.3	0.01														
64	349	-225.0	3225.0	0.0	LC1	CH	0.1	21.3	0.01														
65	265	3225.0	-825.0	0.0	LC1	CH	-0.1	21.3	0.01														
66	267	3400.0	-825.0	0.0	LC1	CH	0.1	21.3	0.01														
67	437	-3225.0	-825.0	0.0	LC1	CH	0.0	21.3	0.00														
68	545	-225.0	-3225.0	0.0	LC1	CH	0.0	21.3	0.00														
61	149	3400.0	-3225.0	-500.0	LC1	CH	0.0	1.5	0.01														
62	596	3225.0	3400.0	-500.0	LC1	CH	0.0	1.5	0.01														
64	729	0.0	-3225.0	-500.0	LC1	CH	0.1	3.3	0.03														
Maximum Displacement by Value / Ratio																							
51	127	0.0	3150.0	-27110.0	LC1	CH	0.8	16.5	0.05														
51	127	0.0	3150.0	-27110.0	LC1	CH	0.8	16.5	0.05														
Minimum Displacement by Value / Ratio																							
51	2332	-2995.8	973.4	-27110.0	LC1	CH	-0.5	16.5	0.03														
51	2332	-2995.8	973.4	-27110.0	LC1	CH	-0.5	16.5	0.03														

FE mesh points Grid points Max: 0.05 ≤ 1

Figure 2.28: Window 3.1 Displacements

Columns A to D are explained in chapter 2.3.1, page 30 ff.

Loading

All actions that have been selected for the deformation analysis are listed by surface in column E. In this way, you can specifically evaluate the maximum deformation for each single load case or load combination.

Combination

This column shows the design situations that have been assigned in window 1.1 *General Data*, tab *Serviceability Limit State* (see chapter 2.1.1.2, page 11):

- Characteristic (CH)
- Frequent (FR)
- Quasi-permanent (QP)

Displacements - u_z

These values represent the governing deformations in direction of the local surface axes z. The maximum deformations u_z refer to the non-deformed original structural system.


To display the local surface axes xyz, use the *Display* navigator in RFEM or the context menu of the corresponding surface (see Figure 2.22, page 31).

Displacements - Limit u_z

This column shows the limit deformations in direction of the z-axis of each surface. These deformations are determined by the reference lengths L of the boundary lines that have been defined in window 1.4 (see chapter 2.1.4, page 18) and serviceability limits of the dialog box *Details*, tab *Serviceability* (see Figure 2.16, page 24).

Ratio

The final column shows the quotients determined from the existing displacement u_z (column G) and the allowable displacement *Limit u_z* (column H). If the limit deformations are kept, the ratio is less than or equal to 1 and the serviceability limit state design was carried out successfully.



Maximum and Minimum Displacement by Value / Ratio

At the bottom of the window, a summary is displayed showing the extreme displacement values u_z (column G) and the extreme stress ratios (Column I) of all designed surfaces. The output is divided in maximum (positive) and minimum (negative) results.

2.3.8 Parts List

Finally, RF-STEEL Surfaces provides a summary of all surfaces that are included in the design case.

4.1 Parts List

Part No.	A	B	C	D	E	F	G
	Material	Thickness Type	d [mm]	Area [m ²]	Coating [m ²]	Volume [m ³]	Mass [kg]
1	Steel S 235	Constant	20.0	4.00	8.00	0.08	628.0
3		Constant	20.0	4.00	8.00	0.08	628.0
4		Constant	20.0	4.00	8.00	0.08	628.0
Sum				12.00	24.00	0.24	1884.0
2	Steel S 355	Constant	20.0	4.00	8.00	0.08	628.0
Sum				4.00	8.00	0.08	628.0
Sum				16.00	32.00	0.32	2512.0

FE mesh points
 Grid points

Figure 2.29: Window 4.1 *Parts List*

Details...

By default, this list contains only the designed surfaces. If you need a parts list for all surfaces of the model, select the corresponding option in the *Details* dialog box, tab *Options* (see Figure 2.17, page 25).

Part No.

The program assigns part numbers to the surfaces that are referring to the surface numbers.

Material

The results are listed by materials. The material column ends with row the *Sum* of the values that are displayed in column D to G.

Thickness

Columns B and C show the *Type* of thickness as well as the thickness *d*. The entries refer to the input data in window 1.3 *Surfaces*.

Area

This column gives information about the area of each surface.

Coating

The surface area is determined from the top and bottom side of a surface. The lateral surfaces of the thin-walled steel surface are not considered.

Volume

The volume of a surface is determined by the product of its thickness and area. If the surface has a variable thickness, the program considers this property accordingly.

Mass

The final column indicates the total mass of each part.

Sum

At the bottom of the list, you find a summary of the summed up values of column D to G. The last data field of the column *Mass* shows the total amount of steel required.

3. RF-STEEL Members

3.1 Input Data

When you have started the add-on module, a new window opens. In this window, a Navigator is displayed on the left, managing the tables that can be selected currently. The drop-down list above the navigator contains the design cases (see chapter 6.1, page 90).

The design relevant data is defined in three input windows. When you open RF-STEEL Members for the first time, the following parameters are imported automatically:

- Members and sets of members
- Load cases, load combinations, result combinations, and RF-DYNAM cases
- Materials
- Cross-sections
- Internal forces (in background, if calculated)

To select a table, click the corresponding entry in the navigator. To set the previous or next input window, use the buttons shown on the left. You can also use the function keys to select the next [F2] or previous [F3] window.

Click [OK] to save the results. Quit RF-STEEL Members and return to the main program. When you click [Cancel], you exit the module but without saving the data.



3.1.1 General Data

In window 1.1 *General Data*, you select the members, sets of members, and actions that you want to design. The design standard will be specified in window 1.2 because the material properties are related to the standard.




Figure 3.1: Window 1.1: *General Data*

Design of




Figure 3.2: Design of members and sets of members



The design can be carried out for *Members* as well as for *Sets of Members*. If you want to design only selected objects, clear the *All* check boxes. Then you can access the input fields to enter the relevant members or sets of members. The list of the numbers preset in the field can be selected by double-clicking it and overwritten by entering the data manually. Use the button [↵] if you want to display the objects graphically in the RFEM work window.



When you design a set of members, the program determines the maximum stress ratio of all members contained in the set of members. The results are shown in the window 2.2 *Stresses by Set of Members*, 3.2 *Governing Internal Forces by Set of Members*, and 4.2 *Parts List by Set of Members*.

Click [New] to create a new set of members. The dialog box that you already know from RFEM appears where you can specify the parameters for a set of members.

Existing Load Cases

In this column, all load cases as well as load and result combinations that have been created in RFEM are listed.



RF-STEEL Members can also design RF-DYNAM cases.




Click [▶] to transfer selected entries to the list *Selected for Design* on the right. You can also double-click the entries. To transfer the complete list to the right, click [▶▶].



To transfer multiple entries of load cases, click the entries while pressing the [Ctrl] key, as common for Windows applications. Thus, you can transfer several load cases at the same time.

Load cases that are marked by an asterisk (*), like load case 6 and 7 in Figure 3.1, cannot be designed: This happens when the load cases are defined without any load data or the load case contains imperfections. Then when you transfer the load cases, a corresponding warning appears.

At the end of the list, several filter options are available. They will help you assign the entries sorted according to load cases, combinations, or action categories. The buttons are reserved for the following functions:



	Select all cases in the list.
	Invert selection of load cases.

Table 3.1: Buttons in the dialog section *Existing Load Cases*

Selected for Design



The column on the right lists the load cases, load combinations, and result combinations selected for design. To remove selected items from the list, click [◀] or double-click the entries.



To transfer the entire list to the left, click [◀◀].



The design of an enveloping max/min result combination is performed faster than the analysis of all load cases and load combinations that have been globally set. However, when analyzing a result combination, the influence of the contained loads is difficult to infer.

Comment



Figure 3.4: User-defined comment

In this input field, you can enter user-defined notes describing, for example, the current design case.

3.1.2 Materials

The window is subdivided into two parts. In the upper part, all materials created in RFEM are listed. In the *Material Properties* section, the properties of the current material, that is the table row currently selected in the upper section, are displayed.




Figure 3.5: Window 1.2 Materials


Materials that will not be used in the design appear in gray lettering. Materials that are not allowed are highlighted red. Modified materials are displayed in blue.

The material properties required for the determination of internal forces are described in the RFEM manual, chapter 4.3 (*Main Properties*). The material properties required for design are stored in the global material library. The values are preset (*Additional Properties*).

To adjust the units and decimal places of material properties and stresses, select in the module's **Settings** → menu **Units and Decimal Places** (see chapter 6.3, page 96).

Material Description

The materials defined in RFEM are already preset, but it is always possible to modify them. To select the field, click the material in column A. Then click [▼] or press function key [F7] to open the material list.



Material	Standard
Steel S 355 DIN 18800:1990-11	DIN 18800:1990-11
Steel S 235	DIN 18800:1990-11
Steel S 275	DIN 18800:1990-11
Steel S 355	DIN 18800:1990-11
Fine Grain Steel S 275 N	DIN 18800:1990-11
Fine Grain Steel S 275 M	DIN 18800:1990-11
Fine Grain Steel S 355 N	DIN 18800:1990-11
Fine Grain Steel S 355 M	DIN 18800:1990-11
Fine Grain Steel S 460 N	DIN 18800:1990-11
Fine Grain Steel S 460 M	DIN 18800:1990-11
Improved Steel C 35+N	DIN 18800:1990-11

Figure 3.6: List of materials

Only "Steel" materials are available in the list. In principle, you can carry out the design with different materials if their stress design concept is based on the comparison of existing normal, shear, and equivalent stresses with allowable stresses (for example the design of cross-sections consisting of aluminum or stainless steel). Of course, you must additionally take into account further standard specifications.

When you have imported a material, the design relevant *Material Properties* are updated.

Limit stresses of a material that is not allowed (for example coniferous timber), and thus highlighted in red, can be defined by means of *Yield Strength* (column C) or by selecting the check box *Manually* (column D) and entering user-defined specifications. When you have defined the allowable stresses in columns E to G, the red color will disappear.

If you change the material description manually and the entry is stored in the material library, RF-STEEL Members will import the material properties, too.

The import of materials from the library is described later.

Safety Factor γ_M

This factor describes the safety factor contained in the design values of the material stiffnesses. Therefore, M is indicated. By means of the factor γ_M , the characteristic value of the yield strength $f_{y,k}$ is reduced in order to determine the limit normal stress $\sigma_{R,d}$ (see Equation 3.1) and the limit shear stress $\tau_{R,d}$ (Equation 3.2).



Thus, for example for DIN 18800, the factor γ_M is considered twice for the design if the calculation is carried out according to second-order or large deformation analysis: According to DIN 18800 part 2, el. (116), you must consider the influence of deformations by a stiffness that is reduced about 10 % when determining internal forces. Moreover, you must reduce the design values of the stiffnesses by the safety factor γ_M when you design the ultimate limit state.

Yield Strength $f_{y,k}$

The yield strength describes the limit to which the material can be strained without plastic deformation. The characteristic values of several steel grades can be found, for example, in EN 1993-1-1, section 3 or DIN 18800 part 1, section 4.

When modifying the yield strength, the limit stresses in column E, F, and G are adjusted automatically.

For some materials, there is a relation between the characteristic yield strength $f_{y,k}$ and the thickness t of the relevant structural component. In the section *Material Properties*, the *Thickness Range* of the material selected above is shown with the corresponding yield strength.



The zones of the yield strength are specified in the standards, for example in DIN 18800 part 1, table 1. To control and, if required, adjust the thickness of structural components including yield strength, click [Edit] (see Figure 3.8 page 46).

Limit Stresses

The limit stresses of materials that are stored in the material library are preset automatically.



If you want to adjust the limit stresses, you can use the check box *Manually* or the button [Edit Material] (see Figure 3.8, page 46).

Manually

If the check box is selected, you can define the limit stresses in column E to G manually.

Modified material properties are marked by an asterisk in the column *Material Description*.

Material No.	A Material Description
1	Steel S 235*

Limit σ_x

The limit normal stress represents the allowable stress for actions due to bending and axial force. According to DIN 18800 part 1, el. (746), it is determined by the characteristic value of the yield strength, reduced by the safety factor γ_M .

$$\sigma_{x,R,d} = \frac{f_{yk}}{\gamma_M}$$

Equation 3.1

Limit τ

The limit shear stress indicates the allowable shear stress due to shear and torsion. To determine the limit shear stress according to DIN 18800 part 1, el. (746), the safety factor γ_M is also taken into account by the equation.

$$\tau_{R,d} = \frac{f_{yk}}{\gamma_M \cdot \sqrt{3}}$$

Equation 3.2

Limit σ_{eqv}

The limit equivalent stress represents the allowable equivalent stress for the simultaneous effect of several stresses. According to DIN 18800 part 1, el. (746), it is determined by Equation 3.1.

Material Library

Numerous materials are already available in the library. To open the corresponding dialog box, click



Edit → **Material Library**

or use the button shown on the left.





Figure 3.7: Dialog box *Material Library*

In the *Filter* section, *Steel* is preset as material category. Select the material quality that you want to use for the design in the list *Material to Select*. The corresponding properties can be checked in the dialog section below.



Click [OK] or press [..] to transfer the selected material to table 1.2 of the add-on module RF-STEEL Members.


Chapter 4.3 in the RFEM manual describes in detail how materials can be filtered, added, or rearranged.

You can also select material categories like *Cast Iron* or *Stainless Steel*. Please check, however, whether these materials are allowed by the standard's design concept.

Edit Material



To adjust the yield strengths and limit stresses of the currently selected material, click the button shown on the left. The following dialog box appears.



Range No.	Thickness t [mm]		Yield Strength $f_{y,k}$ [N/mm ²]	Limit Stresses [N/mm ²]		
	from	to		Limit σ_x	Limit τ	Limit σ_{eqv}
1	0.0	40.0	240.0	218.2	126.0	218.2
2	40.0	100.0	215.0	195.5	112.8	195.5

Figure 3.8: Dialog box *Edit Material*

In the table *Yield Strengths and Limit Stresses Subject to Component Thicknesses*, the limits of the *Component Thickness t* can be shifted by manually entering values in column B. The number of ranges is defined in the standards.

If the check box *User-defined, independent definition of limit stresses* is ticked, you can define the limit stresses for each range individually. If this check box is not active, the limit stresses are determined by the yield strength $f_{y,k}$ (column C) and the safety factor γ_M according to Equation 3.1 and Equation 3.2.

3.1.3 Cross-Sections

This window lists the cross-sections that are used for the design. In addition, the window allows you to specify optimization parameters.




Figure 3.9: Window 1.3 Cross-sections

Cross-Section Description

The cross-sections defined in RFEM are preset together with the assigned material numbers.

If you want to modify a cross-section, click the entry in column B to select this field. Click [Cross-section Library] or [...] in the field or press function key [F7] to open the cross-section table of the current input field (see the following figure).

In this dialog box, you can select a different cross-section or a different row. To select a different cross-section category, click [Back to Cross-section Library] to access the general cross-section library.

Chapter 4.13 of the RFEM manual describes how cross-sections can be selected from the library.







Figure 3.10: IS section types in the cross-section library

The new cross-section description can be entered in the input field directly. If the data base contains an entry, RF-STEEL Members imports these cross-section parameters, too.

A modified cross-section will be highlighted in blue.

If the RF-STEEL cross-sections are different from the ones used in RFEM, both cross-sections are displayed in the graphic in the right part of the window. The stress analysis will be performed with the internal forces from RFEM for the cross-section selected in RF-STEEL.

Max. Design Ratio

This column will be shown after the calculation. It is a decision support for the optimization. By means of the displayed design ratio and colored relation scales, you can see which cross-sections are little utilized and thus oversized, or overloaded and thus undersized.

Optimize

You can optimize every cross-section from the library: Search for the cross-section in the same row that comes as close as possible to a user-defined maximum ratio. The maximum ratio can be defined in the dialog box *Details* (see Figure 3.13, page 51).

If you want to optimize a cross-section, open the corresponding drop-down list in column D or E and select the relevant entry: *From current row* or, if available, *From favorites 'description'*. Recommendations for the cross-section optimization can be found in chapter 6.2 on page 92.

Remark

This column shows remarks in the form of footer numbers that are explained below the cross-section list.



A warning might appear before the calculation: *Incorrect type of cross-section!* This means that there is a cross-section that is not registered in the data base. It may be a user-defined section or a SHAPE-THIN section that has not been calculated yet. To select an appropriate section for the design, click the [Library] button (see description in Figure 3.9).


Member with tapered cross-section

For tapered members with different cross-sections at the member start and member end, the module displays both cross-section numbers, in accordance with the definition in RFEM, in two table rows.

RF-STEEL Members also designs tapered members, provided that the cross-section at the member's start has the same number of stress points as the cross-section at the member's end. The normal stresses, for example, are determined from the moments of inertia and the centroidal distances of the stress points. If the start and the end cross-section of a tapered member have not the same number of stress points, the intermediate values cannot be interpolated. A calculation will not be possible neither in RFEM nor in RF-STEEL.

To produce the same number of stress points, you can, for example, define the second profile as a copy of the cross-section start with adjusted geometry parameters. The easiest way to do this is to describe both cross-sections as parametric profiles. In such a case, the cross-section group *IVU I-Section Plus Lower Flange* is recommended.

The cross-section's stress points including numbering can also be checked graphically: Select the cross-section in window 1.3 and click [Info]. The dialog box shown in Figure 3.11 appears.



Cross-section graphic

In the right part of the window, the currently selected cross-section is displayed.

The buttons below the graphic are reserved for the following functions:







Button	Function
	Opens the dialog box <i>Info about Cross-Section</i> (see Figure 3.11)
	Displays or hides the dimensions of the cross-section
	Displays or hides the principal axes of the cross-section
	Displays or hides the stress points
	Displays or hides the numbering of stress points or c/t-parts
	Resets the full view of the cross-section graphic

Table 3.2: Buttons of cross-section graphic

Info About Cross-Section

In the dialog box *Info About Cross-Section*, you can view the cross-section properties, stress points, and c/t-parts.






Figure 3.11: Dialog box *Info About Cross-Section*



Click the button [Details] to call up detailed information on stress points (distance to center of gravity, statical moments of area, normalized warping constants etc.) and c/t-parts.





Figure 3.12: Dialog box *Stress Points of HE A 400*

3.2 Calculation

3.2.1 Detail Settings



Before you start the calculation by clicking [Calculation], it is recommended to check the design details. The corresponding dialog box can be accessed in all windows of the add-on module by clicking the [Details] button.




Figure 3.13: Dialog *Details*

Display Result Tables


In this dialog section, you can select the results windows including parts list that you want to be displayed. The windows are described in chapter 3.3 *Results*.

Window 2.5 *Stresses by Stress Point* is inactive by default because the stress graphic can also provide an evaluation of the results in the stress points. For a check of stress points listed in tables, activate the display of this window.

The values displayed in window 3.1 *Governing Internal Forces* are related to the maximum equivalent stress σ_{eqv} (default setting). If you want to evaluate the results specifically, you can select a different stress type in the list.

Method of Stress Calculation for Result Combinations

A biaxial loading in different load cases may result in the fact that the combined member internal forces do not produce the maximum stresses. This is the case, for example, when the first load case with vertical load has only M_y moments but no M_z moments, and the second load case with horizontal load has only M_z moments but no M_y moments. If you superimpose the load cases with the value "permanent" in a result combination, RFEM will display in the table 4.6 *Members - Internal Forces* that the moment M_z is not classified as belonging to the maximum moment M_y : The horizontal load does not contribute to the increase of the moment due to vertical load. The RC design is then carried out separately for the maximum moments M_y and M_z so that the simultaneous effect of both moments for the combined analysis of the bending stresses is not taken into account.



Stresses from Internal Forces

This type of calculation makes direct use of the RFEM table 4.6 *Members - Internal Forces*. By processing the maximum or minimum internal forces row by row, the stresses for each extreme value together with the corresponding internal forces are determined.

The advantage is that the values of the result combinations can be used directly. This has a positive impact on the duration of calculation. In addition to that, the designed internal forces become transparent because in the RF-STEEL window 3.1 *Governing Internal Forces by Member* the module displays the result rows from the RFEM results table 4.6 *Members - Internal Forces*.

Calculate Stresses from Single Load Cases and then Combine

This type of calculation is preset to calculate the stresses of result combinations. First, the program determines the normal and shear stresses of the load cases contained in the RC. Then, these stress components are superimposed according to the conditions specified in the combination criterion. Thus, the program ensures that a biaxial bending stress from different load cases results in correct stresses in a biaxial load state.

The calculation is performed for each stress point. The compression, tension and shear stresses determined for each load case are summed up according to the RC superposition criterion and displayed subsequently as stresses of the result combination. The equivalent stress σ_{eqv} represents an exception because it is determined by the RC components of σ_{total} and τ_{total} . A superposition of equivalent stresses from the load cases would not be correct as it would lead to too high stress ratios.

This type of calculation requires more computing time than the direct use of RC internal forces. Furthermore, the values displayed in window 3.1 *Governing Internal Forces by Member* for the equivalent stresses are more difficult to understand.

As pure uniaxial bending usually does not occur in complex 3D models, both calculation methods should show the same ratios in the output.

Combine stresses from individual extreme values

The check box is deactivated by default so that the stresses are considered row by row (table of internal forces from RSTAB or stresses from load case internal forces).

If you select this check box, RF-STEEL Members calculates the stresses not from the according internal forces or stresses but from the extreme values of the internal forces or stress components at each x-location (for example max/min values of N, M_y , and M_z for normal stress). These "extreme value diagonals" guarantee that the most unfavorable constellation is considered (see the text above introducing the section "Method of Stress Calculation").

Consider Plastification

Allow Local Plastification

If a local plastification according to DIN 18800 part 1, el. (749) is allowed, the equivalent stress σ_{eqv} may exceed the allowed limit stress by 10 % in "small areas."

RF-STEEL Members analyzes the conditions mentioned in el. (749) for small areas.

$$|\sigma_N + \sigma_{M_y}| \leq 0,8 \cdot \sigma_{R,d}$$

Equation 3.3

$$|\sigma_N + \sigma_{M_z}| \leq 0,8 \cdot \sigma_{R,d}$$

Equation 3.4

If the conditions are fulfilled, the limit stress for the design of σ_{eqv} will be increased.

Calculate normal stresses with plastic shape factors α_{pl}

According to DIN 18800 part 1, el. (750), stresses can be reduced by plastic shape factors α_{pl} . This reduction refers to the normal stresses σ_M due to the bending moments M_y and M_z .

$$\sigma_M = \left| \pm \frac{M_y}{\alpha_{pl,y} \cdot I_y} \cdot e_z \pm \frac{M_z}{\alpha_{pl,z} \cdot I_z} \cdot e_y \right|$$

Equation 3.5

If you use this plastification option, RF-STEEL Members applies the plastic shape factors $\alpha_{pl,y} = 1.14$ and $\alpha_{pl,z} = 1.25$ mentioned in the standard.

The reduction of normal stresses by plastic shape factors according to DIN 18800 part 1, el. (750) is allowed only for rolled I-shaped cross-sections.



Eccentric Transverse Loads on I-Beams

If transverse loads are introduced on the upper flange of beams, their influence on the bending stress in the lower flange decreases with increasing cross-section depth. For this reason, it is possible to consider eccentrically acting transverse loads by a simplified method for high I-sections. For each(!) rolled or parametrical symmetrical I-section that is set for design, the bending moment M_z is calculated only on the upper flange. RF-STEEL uses a substitute cross-section with half of the moment of inertia I_z for stress determination.

The advantage of this option is that you can enter the loads in the RFEM model in relation to the centroidal axes in order to avoid torsion.

As the ticked check box affects all symmetrical I-sections of the design case, it is recommended to design all high I-beams in a separate RF-STEEL case (see chapter 6.1, page 90).

Equivalent stress σ_{eqv}

In this dialog section, you can adjust the factors for the determination of the equivalent stress.

$$\sigma_{eqv} = \sqrt{f_1 \cdot \sigma_{total}^2 + f_2 \cdot \tau_{total}^2}$$

where f_1 : factor for normal stresses
 f_2 : factor for shear stresses

Equation 3.6

The factors mentioned in DIN 18800 part 1, el. (748) are preset with $f_1 = 1.0$ and $f_2 = 3.0$.

Cross-section Optimization

The optimization is targeted on the maximum stress ratio of 100 %. If necessary, you can specify a different limit value in this input field.

3.2.2 Stresses and Ratio



The normal stresses σ_{total} , τ_{total} , and σ_{eqv} are displayed as presets in the windows 2.1 to 2.5. To display further stress components, click [Select Stresses to Show] and [Extended Stress Diagram] (see Figure 4.2, page 72).

Normal stresses

In RF-STEEL Members, the following rule applies for signs: Tensile stresses are indicated by positive signs and compressive stresses by negative signs (see Figure 3.14).

The analysis is carried out for each single stress point. Therefore, the components of the maximum stresses for a combined calculation (for example σ_{total}) must not be summed up: Often, the maximum stresses occur in different stress points. You have to superimpose the stress components that are available in the same stress point.

The normal stresses σ have the following meanings:

σ_N	Stress due to axial force N $\sigma = \frac{N}{A}$ where A: cross-sectional area of cross-section
σ_{M-y}	Stress due to bending moment M_y $\sigma = \frac{M_y}{\alpha_{pl,y} \cdot I_y} \cdot e_z$ where $\alpha_{pl,y}$: plastic shape factor according to DIN 18800 part 1, el. (750) I_y : second moment of area related to principal axis y e_z : centroidal distance of the stress point in direction z
σ_{M-z}	Stress due to bending moment M_z $\sigma = -\frac{M_z}{\alpha_{pl,z} \cdot I_z} \cdot e_y$ where $\alpha_{pl,z}$: plastic shape factor according to DIN 18800 part 1, el. (750) I_z : second moment of area related to principal axis z e_y : centroidal distance of stress point in direction y
σ_M	Stress due to bending moments M_y and M_z $\sigma = \frac{M_y}{\alpha_{pl,y} \cdot I_y} \cdot e_z - \frac{M_z}{\alpha_{pl,z} \cdot I_z} \cdot e_y$
$\sigma_{tension}$	Tensile stress due to axial force N and bending moments M_y and M_z $\sigma = \frac{N}{A} + \frac{M_y}{\alpha_{pl,y} \cdot I_y} \cdot e_z - \frac{M_z}{\alpha_{pl,z} \cdot I_z} \cdot e_y$
$\sigma_{compression}$	Compressive stress due to axial force N and bending moments M_y and M_z $\sigma = \frac{N}{A} + \frac{M_y}{\alpha_{pl,y} \cdot I_y} \cdot e_z - \frac{M_z}{\alpha_{pl,z} \cdot I_z} \cdot e_y$
σ_{range}	Maximum difference between normal stresses of different load cases that are required, for example, for fatigue design
σ_{total}	Normal stress due to axial force N and bending moments M_y and M_z $\sigma = \frac{N}{A} + \frac{M_y}{\alpha_{pl,y} \cdot I_y} \cdot e_z - \frac{M_z}{\alpha_{pl,z} \cdot I_z} \cdot e_y$

Table 3.3: Normal stresses σ



The local member axis system has a certain impact on the signs of the internal forces and stresses.




Figure 3.14: Positive definition of internal forces

The bending moment M_y is positive if tensile stresses are generated on the positive member side (in direction of the z-axis). M_z is positive if compressive stresses occur on the positive member side (in direction of the y-axis). The sign definition for torsional moments, axial forces, and shear forces conforms to the following convention. These internal forces are positive if they act in a positive direction.



If the *Type of Model* was defined as **2D** in the *General Data* of RFEM, the design of unsymmetrical cross-sections like angles or C-sections needs to be handled with care: In a plane model, only moments about the member axis y are possible so that RFEM performs a division of the moment in the direction of the principal axes u and v. RF-STEEL Members designs only the part of the moment about the y-axis. Therefore, systems with unsymmetrical cross-sections should be checked by means of a spatial model (model type 3D).

Shear stresses

The shear stresses τ have the following meanings:

τ_{V-y}	<p>Stress due to shear force V_y</p> $\tau = -\frac{V_y \cdot Q_z}{I_z \cdot t}$ <p>where Q_z: statical moment related to principal axis z I_z: second moment of area related to principal axis z t: governing thickness of cross-section</p>
τ_{V-z}	<p>Stress due to shear force V_z</p> $\tau = -\frac{V_z \cdot Q_y}{I_y \cdot t}$ <p>where Q_y: statical moment related to principal axis y I_y: second moment of area related to principal axis y t: governing thickness of cross-section</p>
τ_V	<p>Stress due to shear forces V_y and V_z</p> $\tau = -\frac{V_y \cdot Q_z}{I_z \cdot t} - \frac{V_z \cdot Q_y}{I_y \cdot t}$
$\tau_{M-T, St.Venant}$	<p>Stress due to torsional moment M_T in case of open cross-section</p> $\tau = \frac{M_T}{J} \cdot t$ <p>where J: Saint Venant torsional constant t: governing thickness of cross-section</p>
$\tau_{M-T, Bredt}$	<p>Stress due to torsional moment M_T in case of closed cross-section</p> $\tau = \frac{M_T}{2 \cdot A_m \cdot t}$ <p>where A_m: area enclosed by the center lines of the cross-section t: governing thickness of cross-section</p>
τ_{M-T}	<p>Stress due to torsional moment M_T</p> $\tau = \frac{M_T}{J} \cdot t \text{ or } \tau = \frac{M_T}{2 \cdot A_m \cdot t}$
τ_{total}	<p>Shear stress due to shear forces V_y and V_z and torsional moment M_T</p> $\tau = \tau_V + \tau_{M_T}$

Table 3.4: Shear stresses τ

As the equations show, the program uses the statical moments instead of the shear areas of the cross-section to determine the shear stresses due to shear force.



For shear stresses due to torsion, please note:

- If you have a cross-section that is partially open but has one closed cell, the program will classify the entire cross-section as *closed*. The shear stress will be determined exclusively according to the Bredt formula. Thus, STEEL will not perform any pro-rata analysis for $M_{T,St.Venant}$ and $M_{T,Bredt}$ like it is done in the cross-section module SHAPE-THIN.
- The influence of the warping torsion is not considered in RF-STEEL. The design, like the determination of internal forces in RFEM, is limited to the primary torsional moment. However, if you have to consider warping stresses due to the secondary torsional moment or the warping bimoment, it is recommended to use the add-on module RF-FE-LTB for the analysis.

For thin-walled cross-sections, we can assume as a simplification that the shear stress runs parallel to the wall of the cross-section. Therefore, the parts of the shear stresses resulting from both the components of the shear forces are added. The sign of the statical moments defines here which parts are applied positively and which negatively.

The shear stress due to the torsional moment is to be considered differently for the total shear stress, depending on whether it is an open or a closed cross-section. For an open cross-section, the torsion shear stress is added with the sign to that sum from the individual shear stresses that results in the greatest absolute value of the sum.


For a closed cross-section, on the other hand, the torsional shear stress is simply added to the sum from the individual shear stresses. Here, the signs for core area and statical moments are set in such a way that they correspond to the program-specific sign conventions of the shear stress that is dependent on the loading.

Shear stresses within the cross-section

Stress points lying within the cross-section do not permit the assumption mentioned above that the shear stress runs parallel to the wall of the cross-section. Here, a special method with twin stress points is used that creates two stress points with identical coordinates in the cross-section.

The one stress point considers the statical moment about the **y**-axis (parameter for the shear stress due to vertical shear force), the other considers the statical moment about the **z**-axis (parameter for shear stress due to horizontal shear force). For these stress points, the complementary statical moment is zero, respectively. It is possible to assign different thicknesses to the twin stress points that have an influence on the calculation of the shear stress. The shear stresses are considered as interdependent components acting perpendicularly to each other: they are components of one stress state. For the determination of the total shear stress, both parts are quadratically added. The shear stress due to the torsional moment is not considered in these points.

The shear stresses of result combinations in the twin stress points may not be combined linearly. Therefore, the extreme values of both components are evaluated with the corresponding complementary shear stresses in order to determine the greatest total shear stress.



Twin stress points

Equivalent stress

The equivalent stress σ_{eqv} , for example according to DIN 18800 part 1, el. (748), is determined as follows:

σ_{eqv}	Equivalent stress from normal stresses σ and shear stresses τ
	$\sigma_{eqv} = \sqrt{f_1 \cdot \sigma_{total}^2 + f_2 \cdot \tau_{total}^2}$ <p>where f_1: factor for normal stresses f_2: factor for shear stresses</p>

Table 3.5: Equivalent stress σ_{eqv}

Details...

Factors f_1 and f_2 can be defined in the dialog box *Details* (see Figure 3.13, page 51). The factors $f_1 = 1.0$ and $f_2 = 3.0$ are preset according to DIN 18800 part 1, el. (748).

Stress ratio

For stress designs, as described for example in DIN 18800 part 1, el. (747), RF-STEEL Members determines the quotient from the existing and the limit stress.

$$\frac{\sigma}{\sigma_{R,d}} \leq 1$$

Equation 3.7: Design condition for normal stresses


$$\frac{\tau}{\tau_{R,d}} \leq 1$$

Equation 3.8: Design condition for shear stresses

$$\frac{\sigma_{eqv}}{\sigma_{R,d}} \leq 1$$

Equation 3.9: Design condition for equivalent stresses

For each internal force component, you can display the cross-section's stress ratio on the respective stress point (see chapter 4.2.1, page 77). The ratios due to normal, shear, and equivalent stress are displayed in the table output by default.

Max: 0.96 ≤ 1 

If the limit stress is not exceeded, the ratio is less than or equal to 1 and the stress design was carried out successfully.

3.2.3 Start Calculation

Calculation

To start the calculation, click the [Calculation] button that is available in all input windows of the RF-STEEL Members add-on module.

RF-STEEL Members searches for the results of the load cases, load combinations, and result combinations that you want to design. If they cannot be found, the program starts the RFEM calculation to determine the design relevant internal forces.

You can also start the calculation in the RFEM user interface: In the dialog box *To Calculate* (menu *Calculate* → *To Calculate*), design cases of the add-on modules like load cases and load combinations are listed.




Figure 3.15: Dialog box *To Calculate*

If the RF-STEEL design cases are missing in the *Not Calculated* list, select *All* or *Add-on Modules* in the drop-down list below the list.

To transfer the selected RF-STEEL cases to the list on the right, click [▶]. Click [OK] to start the calculation.

To calculate a design case directly, use the list in the toolbar. Select the RF-STEEL Members design case in the toolbar list and click [Show Results].




Figure 3.16: Direct calculation of an RF-STEEL Members design case in RFEM

Subsequently, you can observe the design process in a separate dialog box.

3.3 Results

The window 2.1 *Stresses by Cross-Section* is displayed immediately after the calculation.




Figure 3.17: Results window with designs and stress ratios


The designs are shown in the results windows 2.1 to 2.5, sorted by different criteria.

The windows 3.1 and 3.2 list the governing internal forces. In the last two results windows 4.1 and 4.2, parts lists are displayed by member and set of members.

Every window can be selected by clicking the corresponding entry in the navigator. To set the previous or next input window, use the buttons shown on the left. You can also use the function keys to select the next [F2] or previous [F3] window.

Click [OK] to save the results. You exit RF-STEEL Members and return to the main program.

Chapter 3.3 *Results* describes the different results windows one after the other. Evaluating and checking results is described in chapter 4 *Results Evaluation*, page 71 ff.



3.3.1 Stresses by Cross-Section

In this results window, the maximum stress ratios of all designed members and actions are listed by cross-sections. The ratios for the internal forces of the governing load cases and combinations are sorted by stress types.




Figure 3.18: Window 2.1 Stresses by Cross-Section

Section No.

The results are listed by cross-section numbers. The description of the cross-section is displayed to the right of the cross-section number.

Member No.

It shows the number of the member that bears the maximum stress ratio within the set of members indicated in column E.

Location x

This column shows the respective x-location where the member's maximum stress ratio occurs. For the table output, the program uses the following member locations x:

- Start and end node
- Dividing points according to possibly defined member division (see RFEM table 1.16)
- Member division according to specification for member results (RFEM dialog box *Calculation Parameters*, tab *Global Register Parameters*)
- Extreme values of internal forces

S-Point No.

The design is carried out on certain stress points of the cross-section. These points are defined by centroidal distances, statical moments, and cross-section thicknesses, which allow for a design according to Table 3.3 and Table 3.4 (see page 54).

All default cross-sections of the library as well as the SHAPE cross-sections are provided with stress points on the design relevant cross-section locations. For user-defined cross-sections, the parameters of the stress points must be defined manually or else a design in RF-STEEL Members will not be possible.



The cross-section dialog graphic on the right shows the stress points including numbering. The currently selected stress point (that means the stress point of the table row where the pointer is placed) is highlighted red.



To check the stress point's properties, click [Extended Stress Diagram] (see chapter 4.2.2, page 79).

Loading

Column D displays the numbers of the load cases, load combinations, and result combinations whose internal forces produce the respective maximum stress ratios.

Stress Type

Ratios due to normal stress σ_{total} , shear stress τ_{total} , and equivalent stress σ_{eqv} are set by default. The determination of these stresses is described in Table 3.3, Table 3.4, and Table 3.5 on page 54 to 58.



You can display the components of the total stresses in order to check the data (see Figure 3.19). The stress components can be selected in the dialog box *Stresses - Filter* which can be opened using the button shown on the left (see Figure 4.6, page 77).

Stress Existing

This column displays the extreme values of the existing stresses determined according to the equations in Table 3.3, Table 3.4, and Table 3.5 (see page 54 to 58).

Stress Limiting


This column shows the limit stresses of window 1.2, column E to G (see chapter 3.1.2, page 42). In particular, they are the following:

- Limit normal stress σ_x as the allowable stress for actions due to bending and axial force
- Limit shear stress τ as the allowable shear stress due to shear and torsion
- Limit equivalent stress σ_{eqv} as the allowable equivalent stress for the simultaneous effect of normal and shear stresses

Stress ratio

The last column shows the quotient from the existing and the limiting stress. If the limiting stress is kept, the ratio is less than or equal to 1 and the stress design was carried out successfully.

The length of the colored scales represents the respective stress ratios.



3.3.2 Stresses by Set of Members




Figure 3.19: Window 2.2 Stresses by Set of Members

This results window is displayed when you have selected at least one set of members for the design. The window lists the maximum ratios sorted by set of members.

Column *Member No.* shows the number of the one member within the set of members that bears the maximum stress ratio for the respective stress type.

The output by sets of members clearly presents the design for an entire structural group (for example a frame).

3.3.3 Stresses by Member




Figure 3.20: Window 2.3 Stresses by Member

This results window presents the maximum ratios for different stress types sorted by member number. The columns are described in detail in chapter 3.3.1 on page 61.

If you have a tapered member, both cross-section descriptions are displayed in the table row next to the section number.

3.3.4 Stresses by x-Location




Figure 3.21: Window 2.4 Stresses by x-Location

This results window lists the maximum stresses for each member at all locations x resulting from the dividing points defined in RFEM:

- Start and end node
- Dividing points according to possibly defined member division (see RFEM table 1.16)
- Member division according to specification for member results (RFEM dialog box *Calculation Parameters*, tab *Global Register Parameters*)
- Extreme values of internal forces

3.3.5 Stresses at Every Stress Point




Figure 3.22: Window 2.5 Stresses at Every Stress Point



Details...

This results window is inactive by default because RF-STEEL Members determines the maximum stresses, and thus the governing stress points, automatically. In addition, the windows 2.1 to 2.4 allow you to check the results of each stress point graphically and numerically by clicking [Extended Stress Diagram] (see chapter 4.2.2, page 79).

If a results evaluation by stress points is required, you can display the window by opening the dialog box *Details* (see Figure 3.13, page 51). The dialog box can be opened in every window by clicking [Details].

The stresses in window 2.5 are listed for each member according to *Location x* and *S-Point No.* The different columns of this table are described in detail in chapter 3.3.1 on page 61.

3.3.6 Governing Internal Forces by Member

3.1 Governing Internal Forces by Member

Member No.	A Location x [m]	B Load- ing	D Forces [kN]			F M _T	G Moments [kNm]		
			C N	V _y	V _z		M _y	M _z	
1	6.000	RC1	-54.69	0.49	-60.66	-0.08	-204.52	-0.44	
2	0.000	RC1	-130.16	-5.20	61.36	-0.03	-164.31	-11.42	
3	0.000	RC1	-64.92	-0.19	48.68	0.10	-203.37	-0.35	
4	0.000	RC1	-63.77	-0.35	36.39	-0.08	-76.05	-0.28	
5	4.705	RC1	-60.93	0.33	1.79	-0.10	77.49	0.34	
6	0.000	RC1	-61.06	-0.59	4.76	0.21	75.45	-0.96	
7	3.262	RC1	-64.72	0.12	-36.68	0.10	-78.63	-0.16	
8	3.011	RC1	-66.13	-0.10	-49.13	-0.05	-207.85	0.90	
11	6.000	RC1	-89.74	0.46	-91.77	-0.14	-336.66	-0.29	
12	6.000	RC1	-97.41	-0.04	59.38	-0.08	382.86	0.27	
13	0.000	RC1	-98.28	0.00	70.66	-0.08	-336.72	0.13	
14	0.000	RC1	-96.38	-0.16	59.05	-0.06	-141.34	-0.27	
15	5.378	RC1	-84.16	0.12	1.31	-0.06	156.32	0.56	
16	0.941	RC1	-75.95	-0.26	-0.15	0.06	157.30	0.16	
17	3.262	RC1	-72.18	-0.10	-68.52	0.08	-143.04	0.01	
18	3.011	RC1	-75.17	-0.15	-90.81	-0.10	-383.03	0.78	
21	6.000	RC1	-111.17	-0.59	-102.27	0.20	-372.57	0.49	
22	0.000	RC1	-178.15	-0.25	136.96	0.02	-402.74	-1.58	
23	0.000	RC1	-110.48	-0.07	89.50	0.26	-372.70	-0.24	
24	0.000	RC1	-107.56	0.04	67.69	0.11	-135.84	0.18	
25	5.333	RC1	-95.05	-0.03	-1.18	0.02	154.34	-0.35	
26	0.896	RC1	-107.66	0.14	-0.88	-0.05	152.18	-0.02	
27	3.262	RC1	-134.86	0.02	-69.54	0.02	-161.17	0.10	
28	3.011	RC1	-138.14	0.24	-91.39	0.00	-404.22	-1.19	
31	3.000	RC1	-222.37	-2.10	72.81	-0.09	187.71	0.76	
32	3.000	RC1	-98.36	0.18	-176.74	0.14	-343.44	0.30	
33	0.000	RC1	-216.25	5.02	-0.09	0.00	0.22	3.17	
34	0.000	RC1	-1.18	0.23	-0.04	0.00	0.15	0.83	
35	0.000	RC1	-216.46	5.05	-0.10	0.00	0.35	3.30	
36	0.000	RC1	-1.36	0.20	-0.06	0.00	0.23	0.81	
37	0.000	RC1	-216.24	4.93	-0.09	0.00	0.20	3.32	
38	0.000	RC1	-1.18	0.28	-0.04	0.00	0.15	1.02	
39	3.000	RC1	-222.76	-0.32	-63.94	0.04	-194.07	-0.75	
40	3.000	RC1	-98.56	-0.08	178.80	-0.05	348.43	-0.13	

Figure 3.23: Window 3.1 Governing Internal Forces by Member

Details...

This window displays for each member the governing internal forces, whose stresses result in maximum stress ratios. They refer to the maximum equivalent stress σ_{eqv} by default. In the dialog box *Details* (see Figure 3.13, page 51), which can be accessed by using the [Details] button, you can set another stress type.

If you *Calculate stresses from single load cases in RC and then combine stresses according to RC criteria* (see Figure 3.13, page 51), you disable the direct evaluation of the RC result rows of the RFEM table 4.6 *Members - Internal Forces*. Instead, compression, tension, and shear stresses determined for each load case are summed up according to the RC superposition criterion. The equivalent stress σ_{eqv} represents an exception because it is determined by the RC components of σ_{total} and τ_{total} . Therefore, the governing internal forces for result combinations are not immediately discernible.

Location x

This column shows the respective x-location where the member's maximum stress ratio occurs.

Loading

Column B displays the number of the load case or the load and result combinations whose internal forces produce maximum stresses.

Forces / Moments

For each member, the normal and shear forces as well as the torsional and bending moments producing maximum stresses are displayed.

3.3.7 Governing Internal Forces by Set of Members

3.2 Governing Internal Forces by Set of Members

Set No.	A	B	C			D		E	F	G		H	I
	Location x [m]	Load-ing	N	Forces [kN]		V _y	V _z	M _T	Moments [kNm]		M _y	M _z	
1	3.125	RC1	169.34	0.00	0.00	0.00	0.02	163.37	0.29				
2	3.125	RC1	0.04	0.00	0.00	0.00	0.02	167.00	0.34				
3	3.011	RC1	-66.13	-0.10	-49.13	-0.05	-207.85	0.90					
4	3.000	RC1	-98.36	0.18	-176.74	0.14	-343.44	0.30					
5	0.000	RC1	-216.25	5.02	-0.09	0.00	0.22	3.17					
6	0.000	RC1	-216.46	5.05	-0.10	0.00	0.35	3.30					
7	0.000	RC1	-216.24	4.93	-0.09	0.00	0.20	3.32					
8	3.000	RC1	-98.56	-0.08	178.80	-0.05	348.43	-0.13					

Figure 3.24: Window 3.2 Governing Internal Forces by Set of Members

This window shows the internal forces that result in the maximum stress ratios for each set of members.


3.3.8 Parts List by Member

Finally, RF-STEEL Members provides a summary of all cross-sections that are included in the design case.

4.1 Parts List by Member

Part No.	A Cross-Section Description	B Number Members	C Length [m]	D Total Length [m]	E Surface Area [m ²]	F Volume [m ³]	G Cross-Section [kg/m]	H Mass [kg]	I Total Mass [t]
1	1 - HE A 400 DIN 1025-3:1994	6	6.00	36.00	68.76	0.57	124.82	748.89	4.493
2	2 - IS 360/170/8/14/0 ... 3 - IS 500/170/8/14/0	8	3.01	24.09	36.71	0.19	62.61	188.54	1.508
3	17 - IPE 360 DIN 1025-5:1994	8	3.26	26.10	35.31	0.19	57.07	186.19	1.490
4	17 - IPE 360 DIN 1025-5:1994	8	6.27	50.19	67.91	0.36	57.07	358.05	2.864
5	1 - HE A 400 DIN 1025-3:1994	4	3.00	12.00	22.92	0.19	124.82	374.45	1.498
6	10 - HE A 140 DIN 1025-3:1994	3	3.00	9.00	7.15	0.03	24.65	73.95	0.222
7	10 - HE A 140 DIN 1025-3:1994	2	3.55	7.09	5.63	0.02	24.65	87.41	0.175
8	10 - HE A 140 DIN 1025-3:1994	1	4.09	4.09	3.25	0.01	24.65	100.91	0.101
9	15 - HE A 200 DIN 1025-3:1994	4	3.00	12.00	13.68	0.06	42.23	126.70	0.507
10	16 - Rectangle 200/200	3	3.00	9.00	7.20	0.36	100.00	300.00	0.900
11	6 - HE A 160 DIN 1025-3:1994	2	3.55	7.09	6.43	0.03	30.46	108.00	0.216
12	6 - HE A 160 DIN 1025-3:1994	1	4.09	4.09	3.71	0.02	30.46	124.70	0.125
13	7 - HE A 120 DIN 1025-3:1994	4	6.27	25.10	16.99	0.06	19.86	124.60	0.498
14	9 - IPE 360 DIN 1025-5:1994	8	6.25	50.00	67.65	0.36	57.07	356.68	2.853
15	6 - HE A 160 DIN 1025-3:1994	2	6.55	13.09	11.86	0.05	30.46	199.38	0.399
16	6 - HE A 160 DIN 1025-3:1994	1	7.09	7.09	6.43	0.03	30.46	216.07	0.216
17	12 - QRO 80x4 DIN 59410:1974	25	5.00	125.00	39.13	0.15	9.42	47.10	1.178
18	13 - RD 24 DIN 1013-1	4	7.81	31.24	2.36	0.01	3.55	27.71	0.111
19	13 - RD 24 DIN 1013-1	8	8.02	64.18	4.84	0.03	3.55	28.47	0.228
Sum		102		516.46	427.91	2.74			19.581

Figure 3.25: Window 4.1 Parts List by Member



By default, this list contains only the designed members. If you need a parts list with all members of the model, select the corresponding option in the *Details* dialog box (see Figure 3.13, page 51).

Part No.

The program automatically assigns item numbers to similar members.

Cross-Section Description

This column lists the cross-section numbers and descriptions.

Number Members

This column shows for each part how many similar members are used.

Length

This column displays the respective length of an individual member.

Total Length

This column shows the product determined from the two previous columns.

Surface Area

For each part, the program indicates the surface area related to the total length. The surface area is determined from the *Surface Area* of the cross-sections that can be seen in windows 1.3 and 2.1 to 2.5 in the cross-section information (see Figure 3.11, page 50).



Volume

The volume of a part is determined from the cross-sectional area and the total length.

Cross-Section Mass

The cross-section mass represents the unit mass of the cross-section in relation to the length of one meter. For tapered cross-sections, the program averages both cross-section properties.

Mass

The values of this column are determined from the respective product of the entries in columns C and G.

Total Mass

The final column indicates the total mass of each part.

Sum

At the bottom of the list, you find a summary of the summed up values of column B, D, E, F, and I. The last data field of the column *Total Mass* shows the total amount of steel required.

3.3.9 Parts List by Set of Members

4.2 Parts List by Set of Members

Part No.	A Set of Members Description	B Number Set	C Length [m]	D Total Length [m]	E Surface Area [m ²]	F Volume [m ³]	G Cross-Section [kg/m]	H Mass [kg]	I Total Mass [t]
1	Floor beam B-B	1	25.00	25.00	33.83	0.18	57.07	1426.74	1.427
2	Floor beam A-A	1	25.00	25.00	33.83	0.18	57.07	1426.74	1.427
3	Ridge beam E-E	1	37.10	37.10	57.90	0.38	79.88	2963.35	2.963
4	Column 1-1	1	6.00	6.00	11.46	0.10	124.82	748.89	0.749
5	Column 2-2	1	6.55	6.55	5.20	0.02	24.65	161.35	0.161
6	Column 3-3	1	7.09	7.09	5.63	0.02	24.65	174.86	0.175
7	Column 4-4	1	6.55	6.55	5.20	0.02	24.65	161.35	0.161
8	Column 5-5	1	6.00	6.00	11.46	0.10	124.82	748.89	0.749
Sum		8		119.28	164.50	1.00			7.812

Figure 3.26: Window 4.2 *Parts List by Set of Members*

The last results window is displayed when you have selected at least one set of members for the design. The window summarizes an entire structural group (for example a horizontal beam) in a parts list.

Details on the various columns can be found in the previous chapter. When different cross-sections are used in the set of members, the program averages the surface area, the volume, and the cross-section mass.

4. Results Evaluation

You can evaluate the design results in various manners. The buttons below the tables can be useful for the evaluation process, too.

RF-STEEL Surfaces




Figure 4.1: Buttons for results evaluation in the add-on module RF-STEEL Surfaces

The buttons are reserved for the following functions:

Button	Description	Function
	Stress selection	Opens the <i>Details</i> dialog box to select the displayed stresses → Chapter 4.1.1, page 73
	Show color bars	Turns on and off the colored relation scales in the results tables
	Show rows with ratio > 1	Displays only the rows where the ratio is more than 1, and thus the design is failed
	Result diagrams	Shows or hides the results in the RFEM background graphic → Chapter 4.1.2, page 74
	Excel export	Opens the dialog box <i>Export table</i> → Chapter 6.4.2, page 98
	Surface selection	Allows you to graphically select a surface to display its results in the table
	View mode	Jumps to the RFEM work window to change the view

Table 4.1: Buttons of results windows in RF-STEEL Surfaces

RF-STEEL Members




Figure 4.2: Buttons for results evaluation in RF-STEEL Members

The buttons are reserved for the following functions:

Button	Description	Function
	Cross-section info	Opens the dialog box <i>Info About Cross-Section</i> → Figure 3.11, page 50
	Stress selection	Opens the dialog box <i>Stresses – Filter</i> → Chapter 4.2.1, page 77
	Extended stress diagram	Opens the dialog box <i>Cross-Section Values and Stress Diagram</i> → Chapter 4.2.2, page 79
	Show color bars	Turns on and off the colored relation scales in the results tables
	Show rows with ratio > 1	Displays only the rows where the ratio is more than 1, and thus the design is failed
	Result diagrams	Opens the window <i>Result Diagram on Member</i> → Chapter 4.2.4, page 83
	Excel export	Opens the dialog box <i>Export MS Excel</i> → Chapter 6.4.2, page 98
	Member selection	Allows you to graphically select a member to display its results in the table
	View mode	Jumps to the RFEM work window to change the view

Table 4.2: Buttons of results windows in RF-STEEL Members

4.1 RF-STEEL Surfaces

4.1.1 Selection of Stresses

The following stress types are displayed by default:


- Shear stresses τ_{\max}
- Principal stresses σ in direction of the principal axes 1 and 2 on the surface's top and bottom sides (+)
- Membrane stresses σ_m in direction of the principal axes 1 and 2
- Equivalent stress σ_{eqv}
- Membrane equivalent stress $\sigma_{\text{eqv,m}}$

To activate additional stress components or to hide stresses, click the buttons [Details] or [Select Stresses to Show].

The dialog box *Details* appears (see Figure 2.15, page 19). In the *Stresses* tab, you can specify the stresses relevant for display in the results table. The figure on the left shows the possible stress types.

The different stresses are described in detail in chapter 2.2.1.1, page 20 ff.

The buttons next to the list facilitate the selection of stress types:





Button	Description	Function
	Select All	Selects all stress type check boxes
	Deselect All	Clears all check boxes

Table 4.3: Buttons in dialog section *Stresses to Calculate*

The settings in the *Details* dialog box influence the results tables as well as the printout report: The report displays only stress types shown in the results tables.


4.1.2 Results in RFEM Model

To evaluate the design results, you can also use the RFEM work window.

RFEM background graphic and view mode



The RFEM work window in the background is useful when you want to find the position of a particular FE mesh point or grid point in the model: The point selected in the results window in RF-STEEL Surfaces is signified by an arrow in the background graphic. The surface is highlighted in the selection color. When the button [Show current results in RFEM graphic] is set active, the current stresses are displayed additionally.



RF-STEEL Surfaces - [Damper Flap]										
File Edit Settings Help										
CA2 - General stress analysis of										
2.3 Stresses by Surface										
Surface No.	FE Mesh Point No.	Point Coordinates [m]			Loading	Symbol	Stress [N/mm ²]		Stress Ratio [-]	
		X	Y	Z			Existing	Limit		
45	Material: Steel S 235 - Thickness d: 20.0 mm									
	316	0.393	0.310	1.375	RC1	τ_{max}	1.99	125.97	0.02	
	2822	0.220	0.045	1.375	RC1	$\sigma_{1,+}$	79.71	218.18	0.37	
	456	0.000	-0.225	1.375	RC1	$\sigma_{2,+}$	36.16	218.18	0.17	
	2822	0.220	0.045	1.375	RC1	$\sigma_{1,-}$	79.63	218.18	0.36	
	456	0.000	-0.225	1.375	RC1	$\sigma_{2,-}$	40.23	218.18	0.18	
	2822	0.220	0.045	1.375	RC1	$\sigma_{1,m}$	79.67	218.18	0.37	
	456	0.000	-0.225	1.375	RC1	$\sigma_{2,m}$	38.19	218.18	0.18	
	2823	0.225	-0.006	1.375	RC1	σ_{eqv}	76.74	218.18	0.35	
	2823	0.225	-0.006	1.375	RC1	$\sigma_{eqv,m}$	76.72	218.18	0.35	

Figure 4.3: Indication of surface and current FE mesh point in the RFEM model



Information

You are in the view mode.

In case you cannot improve the display by moving the RF-STEEL Surfaces module window, click [Jump to Graphic] to activate the *view mode*: The program hides the RF-STEEL window so that you can modify the display in the RFEM user interface. The view mode provides the functions of the *View* menu, for example zooming, moving, or rotating the display. The pointer remains visible.

Click [Back] to return to the add-on module RF-STEEL Surfaces.

Graphics

RFEM work window

The stresses and stress ratios can also be checked graphically in the RFEM model. Click [Graphics] to exit the design module. Now, the design results are displayed in the RFEM work window like the internal forces of a load case.

Results navigator

The *Results* navigator is aligned with the add-on module RF-STEEL Surfaces. You can choose various stress types as well as the stress ratios in relation to the individual stress components.





Figure 4.4: RFEM work window with *Results* navigator for RF-STEEL Surfaces



To turn the display of design results on or off, click [Show Results], as you know it from the display of internal forces in RFEM.



As the RFEM tables are of no relevance for the evaluation of the design results, you can hide them.



The design cases can be set by means of the list in the RFEM menu bar.



Panel

You can also evaluate the results using the color panel, which is providing the common control functions. The functions are described in detail in the RFEM manual, chapter 3.4.6. In the second tab, you can set the *Display Factors* for the stresses and stress ratios. The third tab allows you to display the results of selected surfaces (see chapter 4.3, page 85).

Values on Surfaces

You can use all the options from RFEM to display the result values of stresses and stress ratios on surfaces. These functions are described in the RFEM manual, chapter 9.4. The following figure shows the maximum *Extreme Values* of all local peak values.




Figure 4.5: Equivalent stresses with maximum local peak values

The graphics of the design results can be transferred to the printout report (see chapter 5.2, page 86)

RF-STEEL Surfaces

You can return to the add-on module by using the [RF-STEEL Surfaces] panel button.

4.2 RF-STEEL Members

4.2.1 Selection of Stresses

The following stress types are displayed by default in the results windows:

- Normal stress σ_{total}
- Shear stress τ_{total}
- Equivalent stress σ_{eqv}



Click [Select Stresses to Show] to activate further stress components. In this way, you can check the components affecting the total stress. The button is at the bottom of the table (see Figure 4.2).

The dialog box *Stresses - Filter* appears where you can select the stress types.




Figure 4.6: Dialog box *Stresses - Filter*

The stress types are described in Table 3.3 and Table 3.4 on page 54 to 56.

The buttons in the dialog section *To Show* facilitate the selection of stress types. They are described in detail in Table 4.3 on page 73.



The analysis is carried out for each single stress point. Therefore, the components of the maximum stresses for a combined calculation (for example σ_{total}) must not be summed up: Often, the maximum stresses occur at different stress points. You have to superimpose the stress components that are available in the same stress point.



The specifications in the dialog box *Stresses - Filter* also affect the printout report: The report displays only stress types shown in the results windows.

4.2.2 Results on Cross-Section

The results from the table are visualized by a dynamic stress graphic. This graphic shows the stress distribution on the cross-section for the current x-location of the selected stress type. If a different x-location or stress type is selected by mouse-click, this is shown in the graphic. The governing stress point is highlighted in red.

The graphic can display stresses as well as stress ratios.




Figure 4.7: Diagram of normal stresses on cross-section

The buttons below the graphic are reserved for the following functions:

Button	Description	Function
	Stress diagram	Displays or hides the stress points
	Stress ratio	Displays or hides the stress ratios
	Values	Switches on and off the result values
	Cross-section outlines	Displays or hides the cross-section outlines
	Stress points	Displays or hides the stress points
	Numbering	Switches on and off the numbering of stress points
	Show all graphic	Resets the full view of the results graphic

Table 4.4: Buttons of graphic in results windows 2.1 to 2.5



Use the wheel button to maximize or minimize the display. Use the drag-and-drop function to move the stress graphic. The button [Show All Graphic] resets the graphic's full view.



Extended Diagram of stresses and stress ratios

To evaluate every stress point specifically, click [Extended Stress Diagram]. The dialog box *Cross-Section Values and Stress Diagram* opens.




Figure 4.8: Dialog box *Cross-Section Values and Stress Diagram*

The current *Member No.* and the *x*-location on the member are already preset in the dialog section *Position*. To select another member or *x*-location, use the list.

The dialog section *Stress Points* lists all stress points of the cross-section. The two *Coordinates* columns show the respective centroidal distances e_y and e_z . The *Static Moments* columns display the corresponding first moments of area Q_y and Q_z . The final column indicates the *Thickness t* of the cross-section part which is required to determine the shear stresses.

In the *Stresses* dialog section, all stresses are displayed for the stress point that is currently selected in the dialog section above. In this dialog, you can also select a stress type by mouse-click to display its diagrams in the graphic.



Most of the buttons below the graphic are identical with the buttons in the results windows (see Table 4.4, page 78). As usual, they are described by *ScreenTips*. To print the current stress graphic, click [Print] (see chapter 5.2.2, page 88).

4.2.3 Results in RFEM Model

To evaluate the design results, you can also use the RFEM work window.

RFEM background graphic and view mode

The RFEM work window in the background is useful when you want to find the position of a particular member in the model: The member selected in the RF-STEEL Members results window is highlighted in the selection color in the background graphic. Furthermore, an arrow indicates the member's x-location that is displayed in the active table row.




Figure 4.9: Indication of the member and the current Location x in the RFEM model

In case you cannot improve the display by moving the RF-STEEL Members module window, click [Jump to Graphic] to activate the *view mode*: The program hides the RF-STEEL window so that you can modify the display in the RFEM user interface. The view mode provides the functions of the *View* menu, for example zooming, moving, or rotating the display. The pointer remains visible.

Click [Back] to return to the add-on module RF-STEEL Members.



Information

You are in the view mode.

Graphics

RFEM work window

The stresses and stress ratios can also be checked graphically in the RFEM model: Click [Graphics] to exit the design module. Now, the results are displayed in the RFEM work window like the internal forces of a load case.

The *Results* navigator is aligned with the results from the add-on module RF-STEEL Members. You can select various stress types as well as the stress ratios in relation to the individual stress components.




Figure 4.10: *Results* navigator for RF-STEEL Members

To turn the display of design results on or off, use the button [Show Results], as you know it from the display of internal forces in RFEM. To display the result values, use the toolbar button [Show Values] to the right.

As the RFEM tables are of no relevance for the evaluation of design results, you can hide them.

The design cases can be set by means of the list in the RFEM menu bar.



RF-STEEL Members CA1 - Stress analysis
 LC1 - Self-weight
 LC2 - Live load
 CO1 - Design values
 RF-STEEL Surfaces CA1 - Stress analysis
 RF-STEEL Members CA1 - Stress analysis

The graphical representation of the results can be set in the *Display* navigator by selecting *Results* → *Members*. Stresses and stress ratios are displayed *Two-Colored* by default.




Figure 4.11: *Display* navigator: *Results* → *Members*



In case of a multicolor representation (options *With/Without Diagram* or *Cross-Sections*), the color panel is available, providing common control functions. The functions are described in detail in the RFEM manual, chapter 3.4.6.




Figure 4.12: Stress ratios with display option *Without Diagram*

The graphics of stresses and stress ratios can be transferred to the printout report (see chapter 5.2, page 86).

You can return to the add-on module by using the panel button [RF-STEEL Members].

4.2.4 Result Diagrams

You can also evaluate a member's result distributions in the result diagram graphically.

To do this, select the member (or set of members) in the RF-STEEL results window by clicking in the table row of the member. Then open the dialog box *Result Diagram on Member* by clicking the button shown on the left. The button is at the bottom of the window (see Figure 4.2, page 72).

The result diagrams are available in the RFEM graphic. To display the diagrams, click

Results → Result Diagrams for Selected Members

or use the corresponding button in the RFEM toolbar shown on the left.

A window opens, graphically showing the distribution of the results on the member or set of members.




Figure 4.13: Dialog box *Result Diagram on Member*

Use the list in the toolbar above to choose the relevant design case.

The dialog box *Result Diagram on Member* is described in detail in the RFEM manual, chapter 9.5.

- RF-STEEL Members CA1 - Stress analysis
- LC1 - Self-weight
- LC2 - Live load
- CO1 - Design values
- RF-STEEL Surfaces CA1 - Stress analysis
- RF-STEEL Members CA1 - Stress analysis

4.3 Filter for Results

The RF-STEEL results windows allow you to sort the results by various criteria. In some windows of RF-STEEL Surfaces, filter functions can also be used for objects and actions (see Figure 2.26, page 35). In addition, you can use the filter options described in chapter 9.9 of the RFEM manual to evaluate the design results graphically.



You can use the option *Visibility* also for RF-STEEL (see RFEM manual, chapter 9.9.1) to filter the surfaces and members in order to evaluate them.



You can also use or create *Sections* in the RFEM model (see RFEM manual, chapter 9.6.1), which allow you to evaluate the design specifically. To redistribute the stress peaks that are based on singularities, you can use the smoothing function.

Show only failed designs in tables



Use the button shown on the left to exclusively display result rows in which the design conditions are exceeded with stress ratios >1 . Thus you can, for example, filter failed designs to examine the causes in detail.

Filtering results in the work window

Graphics

The stresses and stress ratios can easily be used as filter criteria in the RFEM work window, which can be accessed by clicking [Graphics]. To apply this filter function, the panel must be displayed. If the panel is not active, you can activate it in the RFEM menu by clicking

View → Control Panel (Color Scale, Factors, Filter)

or use the toolbar button shown on the left.



The panel is described in the RFEM manual, chapter 3.4.6. The filter settings for the results must be defined in the first panel tab (Color spectrum). As this register is not available for the two-colored results display, you have to use the *Display navigator* and set the display options *Colored With/Without Diagram* or *Cross-Sections* first (see Figure 4.12, page 82).




Figure 4.14: Filtering equivalent stresses with adjusted color spectrum

As Figure 4.14 shows, the color spectrum can be set in such a way that only equivalent stresses greater than 100 N/mm^2 are shown in a color range between blue and red. Furthermore, the color spectrum can be adjusted in such a way that one color range covers exactly 10 N/mm^2 , for example.

To display the values of grid points or FE nodes, you can use the common RFEM control functions which are described in the RFEM manual, chapter 9.4.

Filtering surfaces and members in the work window

In the *Filter* tab of the control panel, we can specify the numbers of particular members to display their results exclusively, that means filtered. That function is described in detail in the RFEM manual, chapter 9.9.3.




Figure 4.15: Member filter for normal stresses of a hall frame

In contrast to the visibility function, the model will be displayed completely in the graphic. The figure above shows the normal stresses of a hall frame. The remaining designed members are displayed in the model but are shown without stresses.

5. Printout

5.1 Printout report

Similar to RFEM, the program generates a printout report for the RF-STEEL results, to which graphics and descriptions can be added. In this printout report, you decide which data from the design modules should appear in the final printout.



The printout report is described in the RFEM manual. In particular, chapter 10.1.3.4 *Selecting Data of Add-on Modules* provides information concerning the selection of input and output data in add-on modules.



The printout report shows only the stress types that are displayed in the RF-STEEL results windows. Thus, if you want to print the stresses due to axial force, display the stresses $\sigma_{1,m}$ and $\sigma_{2,m}$ in RF-STEEL Surfaces or the stresses σ_N in RF-STEEL Members. The [Selection of Stresses] is described in chapter 4.1.1 on page 73 for RF-STEEL Surfaces and in chapter 4.2.1 on page 77 for RF-STEEL Members.



For large structures with many design cases, it is recommended to split the data into several printout reports, thus allowing for a clearly-arranged printout.

5.2 Printing RF-STEEL Graphics

5.2.1 Results in the RFEM Model

In RFEM, every picture that is displayed in the work window can be included in the printout report or send directly to a printer. Thus, the stresses and stress ratios displayed in the RFEM model can be prepared for the printout, too.



The printing of graphics is described in the RFEM manual, chapter 10.2.



To print the currently displayed graphic of the RF-STEEL results, click

File → Print Graphic

or use the toolbar button shown on the left.




Figure 5.1: Button *Print Graphic* in RFEM toolbar

The following dialog box appears:




Figure 5.2: Dialog box *Graphic Printout*, tab *General*

This dialog box is described in the RFEM manual, chapter 10.2. The RFEM manual also describes the *Options* and *Color Spectrum* tab.

A graphic can be moved anywhere within the printout report by using the drag-and-drop function.

To adjust a graphic subsequently in the printout report, right-click the relevant entry in the navigator of the printout report. The option *Properties* in the context menu opens the dialog box *Graphic Printout*, offering various options for adjustment.





Figure 5.3: Dialog box *Graphic Printout*, tab *Options*

5.2.2 Results on Cross-section



To access the print function, use the dialog box *Cross-Section Values and Stress Diagram*. To open this dialog box, click [Extended Stress Diagram] at the bottom of the results windows (see Figure 4.2, page 72).



In the dialog box *Cross-Section Values and Stress Diagram* (see Figure 4.8, page 79), you have to specify the member, the x-location, and the stress type whose diagram you want to print. Click the [Print] button in the bottom right corner of the dialog box to open the following printing dialog box.




Figure 5.4: Dialog box *Print Info About Cross-Section*

Print Type

In this dialog section, the common options from RFEM are available for selection:

- *Directly to a printer* sends the current graphic to the printer.
- *To a printout report* inserts the graphic into the printout report.
- *To the Clipboard* provides the graphic for other applications.

If several printout reports are available, you can select the number of the target report in the list.

If you want to import several graphics consecutively into the printout report, clear the check box *Show printout report on [OK]*.

Printout Selection

In this dialog section, you decide which details should appear in the print graphic and in the output window. The check boxes for *Graphics of cross-section* are self-explanatory. If you select *Cross-section properties*, the properties will be printed as a table, to which you can add an *Info picture* in the margin. In the same way, you can integrate the properties of the *Stress points* and *c/t-parts* as well as the *Stresses in all stress points* in the printout.




Engineering Office Bavaria Constructions
Joseph-Street 111, 98785 Rainbow Valley
Tel: 09873/1770 - Fax: 09873/1770

Page: 45/52
Sheet: 1
RF-STEEL Members

Project: Model: Hall Date: 24.09.2012

HE A 400 | DIN 1025-3:1994

1 - HE A 400 | DIN 1025-3:1994
Sigma Total
Member No. 22, x: 0.000 m



Min: -188.2 N/mm² (5)
Max: 165.8 N/mm² (5)

Figure 5.5: Stress graphic in printout report

6. General Functions


The final chapter describes useful menu functions as well as export options for the designs.

6.1 Design Cases

Design cases allow you to group surfaces or members for design or to check variants (for example steel grade, calculation of result combinations, optimization).

It is no problem to analyze the same surface or member in different design cases.

To calculate a RF-STEEL design case, you can also use the load case list in the RFEM toolbar.



Create a New Design Case

To create a new design case, use the RF-STEEL menu and click

File → New Case.

The following dialog box appears:




Figure 6.1: Dialog box *New RF-STEEL Surfaces-Case*

In this dialog box, enter a *No.* (that is still available) for the new design case. The corresponding *Description* will make the selection in the load case list easier.

When you click [OK], the RF-STEEL window 1.1 *General Data* opens where you can enter the design data.

Rename a Design Case

To change the description of a design case, use the RF-STEEL menu and click

File → Rename Case.

The following dialog box appears:




Figure 6.2: Dialog box *Rename RF-STEEL Surfaces-Case*

In this dialog box, you can define a different *Description* as well as different *No.* for the design case.

Copy a Design Case

To copy the input data of the current design case, click

File → Copy Case.

The following dialog box appears:




Figure 6.3: Dialog box *Copy RF-STEEL Surfaces-Case*

Define the *No.* and, if necessary, a *Description* for the new case.

Delete a Design Case

To delete design cases, click

File → Delete Case.

The following dialog box appears:




Figure 6.4: Dialog box *Delete Case*

The design case can be selected in the list *Available Cases*. To delete the selected case, click [OK].

6.2 Optimization

The RF-STEEL modules offer you the possibility to optimize the surface thicknesses or cross-sections.



Please note that the internal forces will not be automatically recalculated with the modified surface thicknesses or cross-sections: It is up to you to decide which thicknesses or cross-sections should be transferred to RFEM for a new calculation. As a result of optimized thicknesses or cross-sections, the internal forces may differ significantly because of the changed stiffnesses in the structural system. Therefore, it is recommended to recalculate the internal forces of the modified model data after the first optimization and then to optimize the surfaces or cross-sections once again.

6.2.1 RF-STEEL Surfaces

You can only optimize surfaces in window 1.3 *Surfaces*. To optimize the thickness of a surface, select the check box of this surface in column D or E (see Figure 3.9, page 47). The following dialog box opens.





Figure 6.5: Dialog box *Optimization Parameters*

In the input fields *Minimum* and *Maximum*, you define the upper and lower limits of the allowable surface thicknesses. The current thickness is shown above. The *Increment* determines the interval in which the thickness may vary during the optimization process.

During the optimization process, RF-STEEL Surfaces determines the surface thickness with which the design is carried out in an "optimal" way, that is comes as close as possible to the maximum allowable ratio specified in the dialog section *Global Parameters*. The stress ratio defined in the dialog box *Details*, tab *Options* (see Figure 2.17, page 25) is preset. In this tab, you can define an individual optimization maximum for each surface.

Calculation

When you have recalculated the data, window 1.3 *Surfaces* shows the adjusted thicknesses.

The modified surface thicknesses can be exported to RFEM: Set window 1.3 *Surfaces* and click

Edit → Import All Surfaces to RFEM.

The context menu in window 1.3 also provides options to export optimized surface thicknesses to RFEM.

1.3 Surfaces

Surface No.	Material No.	Thickness Type	d [cm]	Max Stress Ratio [-]	Optimize	Remark	Area A [m ²]	Mass G [t]
1	2	Constant	2.50	0.08	<input type="checkbox"/>	7)	47.08	9.24
2	2	Constant	1.50	0.13	<input type="checkbox"/>		47.08	5.54
3	2	Constant	1.50	0.16	<input type="checkbox"/>		17.58	2.07
4	2	Constant	0.5	0.05	<input type="checkbox"/>		17.58	0.75

Optimize Thickness

Thickness Optimization Parameters...

Export Surface to RFEM

Export All Surfaces to RFEM

Import Surface from RFEM

Import All Surfaces from RFEM

Figure 6.6: Context menu in window 1.3 Surfaces

Before the modified materials are transferred to RFEM, a security query appears as to whether the RFEM results should be deleted (see Figure 6.10, page 95).

Calculation

When you confirm the query and start the [Calculation] subsequently in the RF-STEEL Surfaces add-on module, the RFEM internal forces as well as the design will be determined in one single calculation run.

If the modified surface thicknesses were not been exported to RFEM yet, you can import the original thicknesses in the design module by using the options shown in Figure 6.6. Please note that this option is only available in window 1.3 Surfaces.

6.2.2 RF-STEEL Members

Optimize

From Current Row

No

From current row

From favorites 'BS'

From favorites 'SIA'

RF-STEEL Members offers you the option to optimize overloaded or little utilized cross-sections. To do this, open the drop-down lists in columns D or E of the corresponding cross-sections in the window 1.3 Cross-Sections and select whether the cross-sections should be determined *From the current row* or from user-defined *Favorites* (see Figure 3.9, page 47). You can also start the cross-section optimization out of the results windows by using the context menu.

2.3 Stresses by Member

Member No.	Location x [m]	S-Point No.	Load-ing	Stress Type	Stress [N/mm ²]		Stress Ratio
					Existing	Limiting	
6 Cross-section No. 17 - IPE 360 DIN 1025-5:1994							
6	0				-99.7	218.2	0.46
6	6				-8.7	218.2	0.04
6	1				86.7	218.2	0.40
6	6				11.7	218.2	0.05
6	6				-9.0	126.0	0.07
6	6				-8.8	126.0	0.07
	0.000	10	RC1	Tau M-T	7.0	126.0	0.06
	0.000	1	RC1	Sigma-eqv	100.4	218.2	0.46

Go to Cross-Section Doubleclick

Info About Cross-Section...

Optimize Cross-Section

Cross-Section Optimization Parameters...

Figure 6.7: Context menu for cross-section optimization

During the optimization process, RF-STEEL Members determines the cross-section that fulfills the analysis requirements in the most optimal way, that is, comes as close as possible to the maximum allowable stress ratio specified in the *Details* dialog box (see Figure 3.13, page 51). The required cross-section properties will be determined with the internal forces from RFEM. If another cross-section proves to be more favorable, this cross-section will be used for the design. Then the graphic in window 1.3 will show two cross-sections: the original cross-section from RFEM and the optimized one (see Figure 6.9).

When optimizing a parameterized cross-section, the dialog box *Optimization* appears.




Figure 6.8: Dialog box *Welded Cross-Sections - I symmetric: Optimize*

By ticking the check boxes in the *Optimize* column, you decide which parameter(s) you want to modify. The ticked check boxes activate the *Minimum* and *Maximum* columns, where you can specify the upper and lower limits of the parameter. The *Increment* column determines the interval in which the size of the parameter varies during the optimization process.

If you want to *Keep current side proportions*, tick the corresponding check box. In addition, you have to select at least two parameters for optimization.

Cross-sections based on combined rolled cross-sections cannot be optimized.

The modified cross-sections can be exported to RFEM: Set window 1.3 *Cross-sections* and click **Edit** → **Export All Cross-Sections to RFEM**.

The context menu in window 1.3 provides options to export optimized cross-sections to RFEM.




Figure 6.9: Context menu in window 1.3 *Cross-sections*

Before the modified cross-sections are transferred to RFEM, a security query appears as to whether the results of RFEM should be deleted.




Figure 6.10: Query before transfer of modified cross-sections to RFEM

Calculation

When you confirm the query and start the [Calculation] subsequently in the RF-STEEL Members add-on module, the RFEM internal forces as well as the design ratios will be determined in one single calculation run.

If the modified cross-sections were not exported to RFEM yet, you can import the original cross-sections in the design module by using the options shown in Figure 6.9. Please note that this option is only available in window 1.3 *Cross-sections*.



If you optimize a tapered member, the program modifies the member's start and end and interpolates the second moments of area for the intermediate locations linearly. As these moments are considered with the fourth power, the designs may be inaccurate if the depths of the start and end cross-section differ considerably. In such a case, it is recommended to divide the taper into several members, thus manually modeling the taper layout.

6.3 Units and Decimal Places

Units and Decimal Places for RFEM and the add-on modules are managed in one dialog box. In both RF-STEEL modules, you can use the menu to adjust the units. To open the corresponding dialog box, click

Settings → Units and Decimal Places.

The following dialog box appears which you already know from RFEM. The RF-STEEL Surfaces or RF-STEEL Members module is preset in the list *Program / Module*.




Figure 6.11: Dialog box *Units and Decimal Places*



The settings can be saved as user profile to reuse them in other models. These functions are described in chapter 11.1.3 of the RFEM manual.

6.4 Data Transfer

6.4.1 Material Export to RFEM

When you have adjusted the materials in RF-STEEL for the design, you can export the modified materials to RFEM in a similar manner as you export surfaces and cross-sections: Set window 1.2 *Materials* and then click the menu

Edit → Export All Materials to RFEM.

The modified materials can also be exported to RFEM by using the context menu of window 1.2.



Figure 6.12: Context menu of window 1.2 *Materials*

Calculation

Before the modified materials are transferred to RFEM, a security query appears as to whether the results of RFEM should be deleted. When you confirm the query and start the [Calculation] subsequently in a RF-STEEL add-on module, the RFEM internal forces as well as the designs will be determined in one single calculation run.

If the modified materials have not been exported to RFEM yet, you can transfer the original materials to the design module, using the options shown in Figure 6.12. Please note, however, that this option is only available in window 1.2 *Materials*.

6.4.2 Export of Results

The RF-STEEL results can also be used by other programs.

Clipboard

To copy cells selected in the results windows to the clipboard, use the keys [Ctrl]+[C]. To insert the cells, for example in a word processing program, press [Ctrl]+[V]. The headers of the table columns will not be transferred.

Printout report

The data of the RF-STEEL add-on modules can be printed into the global printout report (see chapter 5.1, page 86) to export them subsequently. Then, in the printout report, click

File → Export to RTF.

The function is described in the RFEM manual, chapter 10.1.11.

Excel / OpenOffice

RF-STEEL provides a function for the direct data export to MS Excel, OpenOffice.org Calc or the file format CSV. To open the corresponding dialog box, click

File → Export Tables.

The following export dialog box appears.





Figure 6.13: Dialog *Export - MS Excel*

When you have selected the relevant parameters, start the export by clicking [OK]. Excel or OpenOffice will be started automatically, that means the programs do not have to be opened first.



1	Set No.	Member No.	Location x [m]	S-Point No.	Load-ing	Stress Type	Stress Existing	Stress Limiting	Stress Ratio
3	1	Floor beam B-B (Member No. 66-69)							
4		68	3,125	6	RC1	Sigma Total	206,4	218,2	0,95
5		66	0,000	13	RC1	Sigma N	34,7	218,2	0,16
6		69	3,125	10	RC1	Sigma M-y	182,6	218,2	0,84
7		68	3,125	6	RC1	Sigma M-z	3,4	218,2	0,02
8		66	6,250	13	RC1	Tau Total	-41,5	126,0	0,33
9		69	0,000	13	RC1	Tau V	41,5	126,0	0,33
10		66	3,125	1	RC1	Tau M-T	-4,2	126,0	0,03
11		68	3,125	6	RC1	Sigma-equiv	206,4	218,2	0,95
12									
13	2	Floor beam A-A (Member No. 71-74)							
14		73	3,125	6	RC1	Sigma Total	187,6	218,2	0,86
15		71	3,125	1	RC1	Sigma N	-0,6	218,2	0,00
16		71	3,125	10	RC1	Sigma M-y	184,8	218,2	0,85
17		73	2,813	6	RC1	Sigma M-z	4,0	218,2	0,02
18		71	0,000	13	RC1	Tau Total	42,0	126,0	0,33
19		71	6,250	13	RC1	Tau V	-41,9	126,0	0,33
20		71	3,125	1	RC1	Tau M-T	-4,3	126,0	0,03
21		73	3,125	6	RC1	Sigma-equiv	187,6	218,2	0,86

Figure 6.14: Result in *Excel*

A Literature

- [1] DIN 18800 Teil 1: Stahlbauten, Bemessung und Konstruktion, 1990
- [2] DIN 18800 Teil 2: Stahlbauten, Stabilitätsfälle, Knicken von Stäben und Stabwerken, 1990
- [3] Erläuterungen zu DIN 18 800 Teil 1 bis 4, Beuth-Kommentar, Beuth Verlag, 2. Auflage 1994
- [4] Eurocode 3 Part 1-1: Design of steel structures, 1993
- [5] PETERSEN, Chr.: Stahlbau, Vieweg und Sohn, Braunschweig/Wiesbaden, 3. Auflage 1993
- [6] SCHNEIDER Bautabellen, Werner Verlag, 20. Auflage 2012
- [7] Stahlbau Handbuch, Band 1, Stahlbau-Verlagsgesellschaft mbH, Köln 1993
- [8] ZIENKIEWICZ, O. C., CHEUNG, Y.K.: The Finite Element Method in Structural and Continuum Mechanics, McGraw-Hill, New York/London, 1967
- [9] KOLÁR, V. et al.: Berechnung von Flächen- und Raumtragwerken nach der Methode der finiten Elemente, Springer Verlag, Wien/New York, 1975
- [10] TIMOSHENKO, S. P., WOINOWSKI-KRIEGER, S.: Theory of Plates and Shells, 2. Auflage, McGraw - Hill, New York, 1959
- [11] KOLÁR, V., NEMEC, I.: Finite Element Analysis of Structures. United Nations Development Program, Economic Com. for Europe, Workshop on CAD Techniques, June 1984, Prague/Geneva, Vol. 1, 248 pp.
- [12] BERGAN, P.G. - FELIPPA, C. A.: A Triangular Membrane Element With Rotational Degrees of Freedom. Computer Methods in Applied Mechanics and Engineering, 50 (1985), 25 - 69
- [13] ZIENKIEWICZ, O.C.: The Finite Element Method in Engineering Science, Mc Graw - Hill, London 3rd Ed., repr. 1979, 787 pp., Chapter 18 - 19 (Nonlinear Problems)
- [14] ŠEVČÍK, I., 3D Finite Element with Rotational Degrees of Freedom, FEM-Consulting s.r.o., Brno
- [15] MANG, H., HOFSTETTER, G.: Festigkeitslehre, Springer Verlag, Wien/New York, 2000

B Index

2	
2D model type.....	55
A	
Action combinations.....	25
Aluminum.....	13, 43
Area.....	39
B	
Bach.....	24
Background graphic.....	74, 80
Buttons.....	71, 72
C	
c/t-part.....	88
Calculation.....	19, 51
Calculation method.....	51
Cantilever.....	19, 25
Characteristic.....	11, 25, 37
Clipboard.....	97
Closed cross-section.....	57
Coating.....	39
Color bars.....	71, 72
Color spectrum.....	84
Colored design diagram.....	84
Combination.....	37
Comment.....	9, 17, 42
Component thickness.....	15, 46, 79
Control panel.....	84
Coordinates.....	30
Coordinates of stress point.....	79
Cross-section.....	47, 93
Cross-section graphic.....	49
Cross-section library.....	47
Cross-section optimization.....	93
D	
Decimal places.....	12, 42, 96
Deformation analysis.....	37
Design.....	48
Design case.....	75, 81, 90, 91
Design of.....	9, 41
Design situation.....	11, 37
Design standard.....	8, 40
Detail settings.....	51
Details.....	19
Displacement limits.....	38
Displacements.....	37
Display factors.....	75
Display navigator.....	82, 84
Distribution of internal forces.....	27
E	
Eccentric transverse load.....	53
Enumeration method.....	25
Envelope method.....	26
Equivalent stress.....	21, 22, 30, 32, 52, 53, 58
Excel.....	97
Exit RF-STEEL.....	8, 40
Export.....	97
Export cross-section.....	94
Export material.....	97
Export surfaces.....	93
Extreme value.....	52
F	
Fatigue design.....	36, 54
Favorite.....	93
FE mesh point.....	26, 35
FE point.....	26, 29, 30
Filter.....	35, 73, 77, 84, 85
Frequent.....	11, 25, 37
G	
General data.....	8, 40
Governing internal forces.....	51, 67
Graphic.....	75, 81
Grid point.....	26, 29, 30, 35
I	
Increment.....	92
Info about cross-section.....	49
Installation.....	6
Internal forces.....	26, 27, 67, 92
L	
Length.....	69
Limit τ	14, 32, 44, 62
Limit σ_{eqv}	14, 32, 44, 62
Limit σ_x	13, 32, 44, 62
Limit state design.....	38
Limit stress.....	13, 32, 43, 44, 52, 62

Line 34
 Load case 10, 11, 41, 62, 67
 Load combination..... 10, 41
 Loading..... 36, 37, 62, 67
 Location x 61, 65

M

Manually adjusted reference length..... 18
 Manually defined limit stresses 13, 44
 Mass 17, 39, 70
 Mass of cross-section 70
 Material..... 12, 15, 33, 42, 46, 97
 Material description 12, 43
 Material library 14, 45
 Material properties 12, 42
 Maximum 36, 92
 Maximum principal stress criterion..... 23
 Maximum shear stress criterion 23
 Member 41, 64
 Membrane equivalent stress..... 21, 22
 Membrane stress..... 20, 21, 30
 Minimum..... 36, 92
 Mixed method..... 26

N

Navigator 8, 40
 Negative side of the surface 20, 21, 22, 31
 Normal stresses..... 54

O

Open cross-section 57
 OpenOffice 97
 Optimization..... 17, 26, 48, 53, 92, 93
 Orthotropy..... 16

P

Panel..... 7, 75, 82, 84
 Parametric cross-section..... 94
 Parts list 38, 69, 70
 Plastic material models 27
 Plastic shape factor α_{pl} 53, 54
 Plastification 52
 Point coordinates 30
 Position..... 38, 69
 Positive side of the surface 20, 21, 22, 31
 Principal strain criterion..... 24
 Principal stress 30
 Print 86, 88

Print graphic..... 86
 Printout report 86, 87
 Printout selection 88

Q

Quasi-permanent..... 11, 25, 37

R

Range 36
 Rankine..... 23
 Ratio 38
 Reference length..... 18, 25
 Remark 17, 48
 Rendering..... 84
 Result combination..... 10, 25, 41, 51, 52, 57, 67
 Result diagrams..... 83
 Result representation 82
 Result values..... 81
 Results evaluation 71
 Results navigator 75, 81
 Results on cross-section 78
 Results tables 26
 Results values..... 76
 Results windows 29, 60
 RF-DYNAM..... 10, 41
 RFEM graphic 86
 RFEM work window 74, 80
 RF-FE-LTB..... 57
 RF-STEEL case..... 53

S

Safety factor γ_M 13, 15, 43, 46
 Section..... 84
 Selecting windows 8, 40
 Selection of stresses..... 73, 77
 Serviceability 11, 18, 24
 Serviceability limit state design 18
 Set of members 41, 63, 68, 70
 Shape Massive 62
 Shape modification hypothesis 22
 SHAPE Thin 62
 Shear stress 20, 21, 30, 56, 79
 Shear stresses..... 57
 Signs..... 54, 55
 Singularity 27, 84, 85
 Smooth range 27
 Smoothing 27

Stainless steel	13, 15, 43, 45	Thickness	16, 39
Start calculation	27, 59	Torsion.....	53, 56, 57
Start RF-STEEL.....	6	Torsional stress	20
Static moment.....	79	Transverse load.....	53
Stress	32	Tresca	23
Stress components	75, 77, 81	Twin stress point	57
Stress design	32, 58, 62	U	
Stress diagram.....	72, 78, 88	Ultimate limit state.....	10, 30
Stress graphic	78	Units	12, 42, 96
Stress point.....	50, 51, 54, 57, 61, 66, 78, 79, 88	Unsymmetrical cross-section.....	55
Stress ranges.....	36	User profile.....	96
Stress ratio	16, 32, 58, 62, 78, 84	User-defined cross-sections	62
Stress type	30, 62, 73	V	
Stresses	19, 20, 29, 30, 54, 56, 60, 62, 64	Variable thickness.....	39
Stresses on cross-sections.....	88	View mode	71, 72, 74, 80
Sum	39, 70	Visibility	84
Surface	16, 18, 33	Volume	39, 70
Surface area.....	17, 69	von Mises	22
Surface axes	37	W	
Surface side	31	Warping torsion	57
Surface thickness.....	92	Windows	8, 40
Surfaces	9	Y	
Symbol.....	30	Yield strength $f_{y,k}$	13, 15, 43, 46
T			
Taper.....	49, 64, 95		